

GLOBAL

LP 2881 series

Postbed machine with stepper motor

Instruction manual & Parts book
**Always switch off the electricity when working on
the machine.**

Safety

1. Safety

1.01 Safety symbols



Danger!
Points to be observed



Danger of injury for operating and specialist personnel!

Caution

Do not operate without finger guard and safety devices.
Before threading, changing bobbin and needle, cleaning etcs switch off main switch.

1.02 Important points for the user

- This Instruction Manual is a component of the machine and must be available to the operating personnel at all times.
- The Instruction Manual must be read before operating the machine for the first time.
- The operating and specialist personnel must be instructed in the safeguards of the machine and safe work methods.
- It is the duty of the user to operate the machine in perfect running order.
- It is the obligation of the user to ensure that none of the safety mechanisms are removed or deactivated.
- It is the obligation of the user to ensure that only authorized persons operate and work on the machine.

Safety

1.03

Danger



A working area of 1 meter is to be kept free both in front of and behind the machine in operation so that the machine is always easily accessible.




Never reach into the sewing area while sewing! Danger of injury by the needle!



Never leave objects on the table while adjusting the machine settings! Objects can become trapped or be slung away! Danger of injury!



Do not operate the machine without support 1! Danger due to top-heavy sewing head! Machine can tip over backwards when tilted!



Safety



Switch the machine off before tilting it backwards!
Danger of injury if the machine is started accidentally!



Do not operate the machine without its take-up-lever guard 2!
Danger of injury due to the motion of the take-up lever!



On machines with thread lubricator, only operate the machine with the eye guard 3 lowered! The eye guard 3 protects the eyes from oil particles from the thread lubrication!



Do not operate the machine without belt guard 4!
Danger of injury by rotating drive belt!



Do not operate the machine without tilt lock 5!
Danger of crushing between sewing head and table top!

Specifications

2

Specifications

Stitch type.....301(lockstitch)

Stitch length

Singl needle.....1.3-7mm

Double needle.....1.3-4.8mm

Clearance under roller presser.....7mm

Clearance width.....245mm

Clearance height.....115mm

Post heighe.....180mm

Sewing head dimensions

length.....approx.615mm

Width.....approx.240mm

Height(above table).....approx.500mm

Bedplate dimensions.....518x177mm

Max.speed

Singl needle.....2500spm

Double needle.....2000spm

Connection data

Operating voltage.....230V±10%, 50/60Hz

Max.power consumption.....1.2KVA

Net weight of sewing head.....approx.61kg

Gross weight of sewing head.....approx.71kg

Subject to alteration


Model

LP 8971

LP 8974

3 Controls

3.01 Pedal




0= Neutral position

1= Sewing

2= Raiser roller presser


3= Trim sewing threads (on machines with-D..)

3.02 Lever for lifting roller presser



- The roller presser can be raised by turning lever 1.

3.03 Knee lever




- The roller presser can be raised by pressing the knee lever 1 in the direction of the arrow.

Controls

3.04


Key for setting stitch length



- The stitch length is set by pressing key 1 and turning the balance wheel.

3.05

Swing out roller presser



- When the roller presser is raised, it can be swung out by pulling it lightly downwards.

Installation and commissioning

4

Installation and commissioning



The machine must only be installed and commissioned by qualified personnel!

All relevant safety regulations must be strictly adhered to!



If the machine is delivered without a table, be sure to use a stand and table top that can hold the weight of the machine with its motor. It is very important to ensure that the stand of the machine is firm and steady, also during sewing.

4.01 Installation


The site where the machine is installed must be provided with suitable connections for electric current.

It must be ensured that the standing surface of the machine site is firm and horizontal, and that sufficient lighting is provided for.



For packing and transportation reasons the table top is in the lowered position. The table height is adjusted as described below.


Adjusting the table height



- Loosen screws 1 and 2 and set the table height as required.
- Firmly tighten screw 1.
- Set the required pedal position and tighten screw 2.


Installation and commissioning

4.02 Fitting the reel stand



- Fit the reel stand as shown in Fig.
- Afterwards insert the stand in the hole of the table top and secure it with the nuts provided.

4.02.01 Fitting the tilt lock



Maschine ausschalten!
Verletzungsgefahr durch unbeabsichtigtes
Anlaufen der Maschine!

- Die im Zubehör befindliche Kippsicherung 1 mit Schraube 2 anschrauben.



Maschine nicht ohne Kippsicherung 1
betreiben! Sicherung 1 betreiben!
Quetschgefahr zwischen oberteil und
Tischplatte!

Installation and commissioning

4.03 Commissioning


- Check the machine, particularly the electrical wiring for any damage.
 - Clean the machine thoroughly and then oil it or fill oil in .
 - Have a mechanic check whether the motor of the machine can be operated with the available power supply, and that the motor is correctly connected in the junction box. If there are any discrepancies. the machine **must not be operated under any circumstances.**



The machine only be connected to an earthed socket!


- When the machine is running, the balance wheel must turn towards the operator. If it does not, the motor connection must be changed by a mechanic.
 - Machines with pneumatic equipment must be connected to the compressed air supply. The pressure gauge should indicate a pressure of 6 bar. If necessary, adjust to the correct setting (see **Chapter 6.01 Checking adjusting the air pressure**).

4.04 Tilted work base




Installation and commissioning

4.05 Tilted work base



4.06 Mounting the table top



Preparation

5

Preparation



All instructions and regulations in this Instruction Manual must be observed .

Special attention must be paid to all safety regulations!




All setting-up work must only be carried out by personnel with the appropriate training. For all setting-up work the machine must be disconnected from its power supply by turning off the on/off switch, or removing the plug from the electric power socket.

5. 01 Inserting needle on model



Switch the machine off! Danger of injury if the machine is started accidentally!



Only use needles of system **134**

- Raise the roller presser **1** and swing it out
- Loosen screw **2** and insert the needles . as far as possible. The long groove must face to the **left** on model LP 8971
- Tighten screw **2** and swing roller presser **1** back to position.



The Choice of needle depends on the model of the machine and the thread and material used .

Preparation

5.02 Winding the bobbin thread; adjusting the primary thread tension



- Place an empty bobbin 1 into bobbin winder spindle 2.
- Thread the bobbin as shown in **Fig.** And wind it clockwise around bobbin 1 a few times
- Switch on the bobbin winder while pressing bobbin winder spindle 2 and lever 3.




The bobbin is filled up during sewing.

- The thread tension of bobbin 1 can be adjusted by knurled screw 4.
- The bobbin winder stops automatically when bobbin 1 is full.

If the thread is wound unevenly:


- Loosen nut 5.
- Turn thread guide 6 accordingly.
- Tighten nut 5.



Preparation

5.03 Removing/Inserting the bobbin case

Switch the machine off! Danger of injury if the machine is started accidentally!




Removing the bobbin case:

- Open the post cap.
- Raise latch 1 and remove bobbin case 2.

Inserting bobbin case:

- Insert bobbin case 2.
- Close the latch and close the post

5.04 Threading the bobbin case/Adjusting the bobbin thread tension



- Insert the bobbin into the bobbin case 1.
- Pass the thread through the slot under spring 2.
- Pass the thread through the notch.
- Adjust the thread tension by turning screw 3.



When the thread is pulled, the bobbin must rotate in the direction of the arrow.

Preparation

5.05 Threading the needle thread and regulating its tension on model LP 8971




Switch the machine off!

Danger of injury if the machine is started accidentally!



- Tilt up the eye guard 1.
- Thread the needle thread as shown in Fig.
- Adjust the needle thread tension by turning milled screw 2.




5.06

Setting the stitch length



- Press key 1 and at the same time turn the balance wheel until the stitch setter clicks into position.
- Hold down key 1 and turn the balance wheel to and fro until the stitch length required is shown on the scale 2 opposite the bottom edge 3 of the belt guard recess.



Care and Maintenance

6


Care and Maintenance

Clean.....	daily, more frequently if in continuous operation
Oil level (thread lubrication/hook lubrication)	daily, before use
Oil the hook.....	daily, before use
Lubricate the bevel gears.....	once a year
Check/adjust air pressure.....	daily, before use
Clean air filter of air filter/lubricator.....	when required



These maintenance intervals are calculated for the average running time of a single shift operation. If the machine is operated more than this, shorter intervals are recommended.

6.01 Checking and adjusting the air pressure (on the pneumatic machine)




- Before operating the machine, always check the air pressure on gauge 1.
- Gauge 1 must show a pressure of **6 bar**.
- If necessary adjust to this reading.
- To do so, pull knob 2 upwards and turn it so that the gauge shows a pressure of **6 bar**.

Care and Maintenance

6.02 Clean the air filter of the air-filter/lubricator (on the pneumatic machine)



Switch the machine off!
Disconnect the air hose at the air-filter/lubricator.



Draining water bowl 1:

- Water bowl 1 drains itself automatically when the compressed-air hose is disconnected from the air-filter/lubricator.

Cleaning filter 2:

- Unscrew water bowl 1.
- Take out filter 2.
- Clean filter 2 with compressed air or isopropyl alcohol.
- Screw in filter 2 and screw on water bowl 1.


6.03 Cleaning

Clean the hook, hook compartment and toothed wheel 3 every day,
several times if in continuous use

Switch the machine off!

Danger of injury if the machine is started accidentally!

Care and Maintenance




- Bring the needle bar to its highest position.
- Open the post cap and remove the bobbin case cap and the bobbin.
- Unscrew hook gib 1.
- Turn the hand wheel until the point of bobbin case 2 penetrates into the groove of the hook race approx. 5mm.
- Remove bobbin case 2.
- Clean the hook race with paraffin.
- When inserting the bobbin case 2, ensure that the horn of the bobbin case 2 engages in the groove of the needle plate.
- Screw hook gib 1 back on and close the post cap.

6.04 Oiling the hook



Switch the machine off!


Danger of injury if the machine is started accidentally!



- Pour **1-2 drops** of oil into hole 1 of the hook gib daily.
- Before commissioning the machine, and after long periods out of operation, pour a few drops of oil into the hook race (see arrow).

Care and Maintenance

6.05 Oil bowl for hook lubrication



Check the oil level before each use. There must always be oil in reservoir 1.

If required refill oil through hole.




Use only oil with a mean viscosity of 22.0mm²/s at 40°C and a density of 0.865g/cm³ at 15°C.



6.06 Filling the oil reservoir of the thread lubrication unit



Control the oil level before each use.
There must always be oil in the reservoir 1.



- If necessary, fill oil up to mark through hole

We recommend thread lubricating oil .

Care and Maintenance

6.07 Lubricating the bevel gears

Switch the machine off!

Danger of injury if the machine is started accidentally!

- All bevel gears must be supplied with new grease once a year.
- Tilt the sewing head back onto the support.



Fig. shows the bevel gears of the

- Apply grease to all the tooth flanks and the rack (see arrows).
- To set the sewing head upright, press tilt lock 1 backwards and set the sewing head upright using both hands.




Use both hands to set the sewing head upright!

Danger of crushing between the sewing head and the table top!



We recommend sodium grease with a dripping point of approx.150C.



7

Adjustment



Unless stated otherwise, during all adjustment work the machine must be disconnected from electric and pneumatic power supply!
Danger of injury if the machine is started accidentally!

7.01

Notes on adjustment

- All following adjustment are based on a fully assembled machine and may only be carried out by expert staff trained for this purpose.
- Machine covers, which have to be removed and replaced to carry out checks and adjustments, are not mentioned in the text.
- The order of the following chapters corresponds to the most logical work sequence for machines which have to be completely adjusted. If only specific individual work steps are carried out, both the preceding and following chapters must be observed.
- Screws, nuts indicated in brackets () are fastenings for machine parts, which must be loosened before adjustment and tightened again afterwards.

7.02

Tools, gauges and other accessories

- 1 set of screwdrivers with blade widths from 2 to 10 mm
- 1 set of open ended wrenches with opening sizes from 7 to 13 mm
- 1 set of allen keys from 1.5 to 6mm
- 1 clamp
- 1 metal ruler
- 1 gauge
- Sewing thread and test material

Adjustment

7.03 Adjusting the basic machine


7.03.01 Needle position in sewing direction on the LP 8971

Requirement

With the stitch length set at its minimum, the needle should be positioned in the centre of the needle hole, as seen in the direction of sewing.



- Set the minimum stitch length.
- Adjust needle bar (screw 1) according to the **Requirement**.



Adjustment


7.03.02 Preliminary adjustment of the needle height

Requirement

When the needle bar is at top dead centre, there must be a clearance of approx. 21mm between the needle point and the needle plate.



- Adjust needle bar 1 (screw 2). Without turning it, according to the Requirement.




Adjustment

7.03.03 Needle rise, hook clearance, needle height and needle guard on the LP 8971

Requirement

With the needle bar positioned **2.0mm** after bottom dead centre and the stitch length set at “**0.8**” :

1. the hook point must be at needle centre with a hook-to-needle clearance of **0.05 to 0.1mm**.
2. the top of the needle eye must be **0.8 to 1.0 mm** below the hook point.
3. The needle guard **6** must touch the needle lightly.




Adjustment



- Loosen screw **1, 2, 3, 4** and **5**.
- Bring needle bar to **2.0 mm** past bottom dead centre.
- Set hook point at needle centre, making sure that the needle is not deflected by needle guard **6**.
- Adjust needle height according to **Requirement 2**.
- Adjust hook post according to **Requirement 1** and tighten screw **4**.
- Making sure that there is some play in the bevel gear, tighten screws **2**.
- With retaining collar **7** touching bevel gear **8** tighten screws **1**.
- Adjust needle guard **6** (screw **9**) according to **Requirement 3**.



When the hook is changed, make sure that the markings **10** and **11** are both on one side.



Adjustment


7.03.04 Needle position crosswise to sewing direnction on the LP 8971

Requirement

As seen crosswise to the sewing direction, the needle must penetrate in the centre of the needle hole.



- Adjust feed wheel post 1 (screws 2, 3 and 4) according to the Requirement.



Adjustment


7.03.05 Height and stroke of the bobbin case opener

Requirement

1. The top edges of the bobbin case opener 1 and bobbin case 3 should be on one level.
2. when the bobbin case opener 1 has deflected the bobbin case to its furthest point, the catch of the bobbin case should be from 0.3 to 0.5 mm from the back edge of the needle plate recess.



- Adjust bobbin case opener 1 (screw 2) in accordance with Requirement 1.
- Turn the balance wheel until the bobbin case opener has deflected the bobbin case to its furthest point.
- Adjust bobbin case opener 1 (screw 2) in accordance with Requirement 2.



On the LP 8974 these adjustments must be repeated on the right post.
Depending on the thread size, a variation of the setting in Requirement 2 is permitted.

Adjustment


7.03.06 Height of the feed wheel on the LP 8974

Requirement

1. when pressure is applied to the feed wheel 4, it should protrude from the needle plate by tooth height (approx. **0.8 mm**).
2. when no pressure is applied to the feed wheel 4, it should have a vertical play of approx. **0.3 mm**.



- Swing out the roller presser
- Loosen screws 1 and 2 (two screws each).
- Adjust drive wheel 3 according to **Requirement 1**, taking care to see that the teeth of drive wheel 3 and feed wheel 4 lock into each other properly.
- Tighten screws 1.
- Adjust guide 5 according to **Requirement 2** and tighten screws 2.




7.03.07 Height of the feed wheel on the

Requirement

Feed wheel should protrude from the needle plate by tooth height (appro. 0.8 mm).



- Swing out the roller presser
- Loosen screws 1.
- Adjust eccentric 3 (fastening screw accessible through hole 2)according.
- Tighten screws 1.



Adjustment


7.03.08 Stitch length control eccentric

Requirement

When the needle (with maximum stitch length set), coming from top dead centre, is **3 mm** above the needle plate, the crank **3** must have reached its front point of reversal.



- Set the maximum stitch length.
- Turn stitch length control device **1** (screws **2**) according to **Requirement**.



Adjustment


7.03.09 Stitch length scale disk

Requirement

When the stitch length control device is locked in position, and the maximum stitch length is set, the marking line of the highest number on the scale disk 1 must be opposite the lower edge 3 of the belt guard recess.



- Set the maximum stitch length.
- Turn the scale disk 1 according to the **Requirement**.



Adjustment


7.03.10 Shaft crank to feed wheel drive

Requirement

When the maximum length is set, the linkage rod 3, or linkage rods 3 and 4 on the model LP 8971 must be able to move freely when the balance wheel is turned.



- Set the maximum stitch length.
- Twist or shift the shaft crank 1 (screw 2) according to the Requirement.




7.03.11 Shaft crank to roller presser drive

Requirement

When the maximum stitch length is set, the linkage rods 3 and 4 must be able to move freely at their left and right point of reversal when the balance wheel is turned.



- Set the maximum stitch length
- Twist or shift the shaft crank 1 (screw 2) according to the Requirement.



Adjustment


7.03.12 Clearance between roller presser and feed wheel

Requirement

When the presser bar lifter is raised, the clearance between the roller presser and the feed wheel must be **7 mm**.



- Raise the presser bar lifter.
- Adjust the presser bar **1** (screws **2**) according to the **Requirement**.
Make sure that the roller presser is parallel to the feed wheel.



7.03.13 Roller presser


Requirement

When the roller presser 1 is touching the feed wheel 5 it must:

1. be parallel to feed wheel 5, as seen in the direction of sewing.
2. be in the centre of the needle (on model 8974 the left needle), as seen in the direction of sewing.
3. be as near as possible to the needle (on model 8974 the left needle), as seen crosswise to the direction of sewing.



- Raise the roller presser.
- Always observe **Requirement 1** for subsequent adjustments.
- Adjust roller presser 1 (screw 2) according to **Requirement 2**.
- Lower roller presser 1 to rest on feed wheel 5.
- Adjust roller presser bracket 3 (screw 4) according to **Requirement 3**.



When sewing very tight curves, the roller presser 1 must be moved a little towards the operator.

Adjustment

7.03.14 Stitch length on stitch length scale


Requirement

When the stitch length is set at "3", and after the needle has entered a strip of leather **11 times**, the total length from the first to last needle penetration must be **30 mm**.



- Set stitch length "3".
- By turning the balance wheel, let the needle enter **11 times** and measure the total length.
- Adjust clamp 1 (screw 2) according to the Requirement.

Clamp 1 must not be positioned diagonally to the rock shaft!



7.03.15 Synchronization of roller presser and feed wheel

Requirement


After **30 needle penetrations** in a strip of leather the total length from the first the the last penetration should be the same, both in the lower and the upper leather layer.



- Set stitch length “3” .
- By turning the balance wheel, let the needle enter **30 times**.
- Compare the total sewn length of the lower and upper leather layer.
- Adjust clamp 1 (screw 2) according to the **Requirement**.



Clamp 1 must not be positioned diagonally to the rock shaft.



Adjustment

7.03.16 Retainer(only on 8974)


Requirement

The retainer **1** must:

1. be as close as possible to the needle, as seen in the direction of sewing .
2. be in the centre of the needle, as seen crosswise to the direction of sewing.
3. when the roller presser is lowered, the distance between the retainer **1** and the workpiece must be **0.2-0.3 mm**.



- Adjust retainer **1** (screw **2**) according to Requirement 3.
- Adjust bracket **3** (screw **4**) according to Requirement 1 and 2.




7.03.17 Knee lever

Requirement

1. before the roller presser rises, the knee lever must still have a slight play.
2. when the knee lever is raised as far as possible, the lever for the roller presser must drop automatically.
3. knee lever bar 5 must be at an angle of approx. 75° to the bedplate.



- Adjust screw 1 (nut 2) according to Requirement 3.
- Adjust screw 3 (nut 4) according to Requirement 2.
- Set bar 5 (screws 6) according to Requirement 3.



Adjustment



7.03.18 Needle thread tension release

Requirement

1. when the presser bar lifter is raised, the tension discs 3 should be pressed at least **0.5 mm** apart.
2. When the roller presser is lowered, the tension must be fully effective.



- Align tension mounting plate **1** and pressure plate **2** according to Requirement.



7.03.19 Thread check spring

Requirement


1. the movement of thread check spring 7 should be completed when the needle point penetrate the fabric (spring stroke approx. 7 mm).
2. when the largest thread loop is formed while the thread is passed around the hook, the thread check spring 7 should rise slightly from its support.



- Adjust support 1 (screw 2) according to **Requirement 1**.
- Adjust the spring tension by turning screw 3 (screw 4).
- Adjust the thread regulator 5 (screw 6) according to **Requirement 2**.



For technical reasons it may be necessary to deviate from the specified spring stroke or spring tension. Move the thread regulator 5 (screw 6) towards “+” (= more thread) or “-” (= less thread).



Adjustment


7.03.20 Bobbin winder

Requirement

1. when the bobbin winder is engaged, the winding spindle must be driven reliably. When the bobbin winder is disengaged, the friction wheel 5 must not be moved by drive wheel 1.
2. the bobbin winder must switch itself off, when the filled thread is about 1 mm from the edge of the bobbin.



- Position drive wheel 1 (screws 2) according to Requirement 1.
- Position bolt 3 (screw 4) according to Requirement 2.



Adjustment


7.03.21 Pressure of roller presser

Requirement

The material must be fed smoothly. No pressure marks should be visible on the material.



- Adjust roller pressure with screw 1 according to the **Requirement**.



Adjustment


7.03.22 Re-engage safety coupling



The coupling **1** is set by the manufacturer. When the thread jams, the coupling **1** disengages in order to avoid damage to the hooks.
A description of how to engage the coupling follows.



- Remove jammed thread.
- Hold coupling **1** with screw **2** and turn the balance wheel, until you feel coupling **1** snap back into place again.



Adjustment

7.04 Adjusting the thread trimmer


7.04.01 Resting position of the roller lever/ radial position of the control cam

Requirement

1. when the thread trimmer is in resting positon, lever 5 should be touching piston 6 and the roller of roller lever 7 should be 0.3 mm away from control cam 3.
2. when the take-up lever is at top dead centre, control cam 3 should just have placed roller lever 7 in its resting position.



- Having made sure that piston 6 is positioned against the left stop, adjust magnet 1 (2 screws) in accordance with Requirement 1.
- Adjust control cam 3 (screw 4) in accordance with Requirement 2.



Adjustment

7.04.02 Position of the thread catcher holder

Requirement


1. there should be a minimum amount of play between toothed wheel 3 and toothed segment 4.
2. both in the neutral position and the foremost position of the catcher, the distance between the toothed segment 4 and the outer edge of the thread catcher holder 1 should be the same (see arrow).



- Adjust the thread catcher holder 1 (screws 2) according to Requirements.



If Requirement 2 cannot be fulfilled, loosen screw 2 and move the toothed segment 4 by one tooth.



Adjustment


7.04.03 Distance between thread catcher and needle plate

Requirement

During its swivel movement thread catcher 1 should not pass the edge of the needle plate (see arrow).



- Move thread catcher 1 (screws 2, two screws) parallel to the thread catcher holder in accordance with the Requirement.



Adjustment

7.04.04 Position of the thread catcher

Requirement


1. the bottom edge of the thread catcher 1 should be at a distance of **0.1 mm** from the positioning finger of the bobbin case 5.
2. when the thread trimmer is in its neutral position, the rear edge of thread cather should be positioned approx. **2.5 - 3 mm** behind the edge of the knife.



- Move thread catcher 1 (screw 2, two screws) in accordance with **Requirement 1**.
- Turn thread cather 1 (screw 3) in accordance with **Requirement 2**.




Thread catcher 1 must be parallel to the surface of the thread catcher holder 4.



7.04.05 Bobbin thread retaining spring

Requirement

1. the bobbin thread clamp spring should be guided reliably in the thread groove of the thread catcher 3.
2. the tension of the bobbin thread spring clamp should be as low as possible, but the bobbin thread should be reliably after the cutting operation.



- Adjust bobbin thread clamp spring 1 (screw 2) in accordance with Requirement 1.
- Adjust the tension in accordance with Requirement 2 by bending side 4 of the bobbin thread clamp spring 1.

Control requirement 1

- Switch off the machine and bring the take-up lever to its bottom dead centre.
- Engage and disengage the thread catcher 3 by hand and check Requirement 1. Adjust if necessary.

Control requirement 2


- After the thread has been cut, sew a few stitches by turning the balance wheel, checking whether the bobbin thread is drawn out of the bobbin thread clamp spring between the 1st and 3rd stitched, if necessary, correct the tension.

Adjustment

7.04.06 Manual cutting test

Requirement

1. when thread catcher 1 is on its forward stroke, it must not carry bobbin thread 3 forward too.
2. when thread catcher 1 is in its front position, bobbin thread 3 must be held reliably by hook 4.
3. After the trimming action, both the needle thread and the bobbin thread must be perfectly cut and bobbin thread 3 retained.





- Sew a few stiches.
- Turn off the on/off switch.
- Carry out the cutting operation manually.
- Check **Requirement 1** and **2**, and if necessary readjust thread catcher 1 in accordance with **Chapter 7.04.04 Position of the thread catcher**.
- Check **Requirement 3**, and if necessary readjust the bobbin thread retaining spring 2 in accordance with **Chapter 7.04.05 Bobbin thread retaining spring**.

Adjustment

7.04.07 Releasing the tension

Requirement

When the magnet is activated, tension discs 3 must be at least **0.5 mm** apart.




- Activate the magnet.
- Detach the tension bearing plate 1 and adjust pressure plate 2.

Adjustment

7.04.08 Linkage rod (only for the 8972)

Requirement

When the thread trimmer is in its resting position, the drive levers **1** must be parallel.



● Adjust drive levers **1** (screw **2**) in accordance with the Requirement.


Adjustment

7.05 Adjusting backtacking mechanism

7.05.01 Needle in needle hole (only for pneumatic machine)

Requirement

When the maximum stitch length is set, the needle must be the same distance from the inside edge of the needle hole, both for forward and reverse stitch.




- Turn crank 1 (screw 2) according to the Requirement,

Adjustment

7.05.02 Needle in needle hole (only for LP 98971)

Requirement:

When the maximum stitch length is set, needle bar should at lowest position.
Press back tacking spanner, needle bar should keep quiescent condition.




- Turn adjustment crank 2 (screw 1) according to requirement.

7.05.03 Coupling for roller presser drive

Requirement

There must be a distance of **3 mm** between coupling half 1 and locking disc 3 of the drive mechanism.




- Adjust coupling half 1 (screw 2) according to the Requirement.

Adjustment

7.05.04 Adjustment for roller presser clutch device (only for LP 8971)

Requirement

1. When sewing forwarders, turn up-feeding wheel by hand, up-feeding wheel by hand 4 just can be rotated in counterclockwise.
2. When sewing forwarders, turn up-feeding wheel by hand, up-feeding wheel by hand 4 can be rotated in counterclockwise and clockwise.




- Press back-tacking spanner 1.
- Adjust connecting plate 2 (screw 3) according to requirement.

Adjustment

7.05.05 Bevel gears for feed wheel drive (only for pneumatic machine)

Requirement

1. bevel gear 3 must fit well on the left side.
2. there must be a distance of **14 mm** between bevel gear 3 and bevel gear 5.




- Remove control unit 1 (screws 2).
- Adjust bevel gear 3 (screw 4) according to Requirement 1.
- Adjust bevel gear 5 (screw 6) according to Requirement 2.

Adjustment

7.05.06 Bevel gears for feed wheel drive (on the LP 8971)

Requirement

1. the right side of bevel gear 1 must be flush with its drive shaft (see arrow).
2. there must be a distance of **13 mm** between bevel gear 3 and bevel gear 1.




- Adjust bevel gear 1 (screws 2) according to Requirement 1.
- Adjust bevel gear 3 (screws 4) according to Requirement 2.

Adjustment

7.05.07 Bevel gear play (only for pneumatic machine)

Requirement


1. when sewing forwards, there must be a slight play between bevel gear **6** and **7**.
2. When sewing backwards, there must be a slight play between bevel gear **6** and **8**.



- Disconnect air supply of the air filter/lubricator.
- Move unit **1** by hand as far as possible to the right (see arrow).
- Adjust screw **2** (nut **3**) according to **Requirement 1**.
- Move unit **1** by hand as far as possible to the left (see arrow).
- Adjust screw **4** (nut **5**) according to **Requirement 2**.

USER MANUAL FOR STEP ROLLER FEED MACHINE

1: Boot interface



Boot screen icon description:



Sewing confirmation key. Click this key, the spindle motor and the pendulum motor will find the origin point, and the system will enter the sewing mode.



Factory setting key. Press and hold this key, the system will enter the factory setting mode.
(It will state individually).



System information key. Long press this key will enter to the system information mode.
The information mode includes the system software version for the panel and control box, and the software upgrade function for the panel and control box. Enter to this mode, the system cannot return. If you need to enter other modes, please turn off the power and restart the machine.

2: Sewing interface

The sewing interface is divided into three categories: free sewing, overlapping sewing, and programmed sewing.



Figure 1: Free sewing interface



Figure 2: Overlapping sewing interface



Figure 3: Programmed sewing interface


2.1: Key description



Start back-tacking. The white font icon indicates that this function is activated and the dark gray font icon indicates that this function is invalid.



End back-tacking. The white font icon indicates that this function is activated and the dark gray font icon indicates that this function is invalid.



The position of the needle when stop. The previous icon indicates that the needle is under the cloth after stop, and the latter icon indicates that the needle is on the cloth after stop.



The presser foot is lift or not when stop the machine. The white font icon indicates that this function is activated and the dark gray font icon indicates that this function is invalid.



The presser foot is lift or not after trimming stop machine. The white font icon indicates that this function is activated and the dark gray font icon indicates that this function is invalid. When activated, the presser foot position is in the upper position after stop trimming. When not activated, the presser foot position is in the lower position. The default state is not activated.



Trimming function. The white font icon indicates that this function is activated and the dark gray font icon indicates that this function is invalid. When activated, the current sewing section can be trimming. If not activated, the current sewing section cannot be trimming.




Rotational speed setting. The white font icon indicates that this function is activated and the dark gray font icon indicates that this function is invalid. When activated, click the "scroll key" , find the speed setting item. Press corresponding the "+" and "-" keys, it can adjust speed. Under the free sewing mode, you can

change speed of "start back-tacking", "end back-tacking" and the current segment. Under the overlapping sewing and programmed sewing it just can change current segment speed.



Back-tacking setting. The white font icon indicates that this function is activated and the dark gray font icon indicates that this function is invalid. This key is used for programming sewing and pattern editing. In the programming sewing, it is used for instantly change the current sewing segment direction. In the pattern editing, it is used for setting current programming segment sewing direction, the reverse direction is activated, the normal sewing direction is not activated.



Needle position setting. the white font icon indicates that this function is activated and the dark gray font icon indicates that this function is invalid. When it need to use needle position function, please setting the spindle parameter P12 “Needle position function” setting value to 1, turn on this function. Then activate the needle position setting key. Needle position angle setting ref to “needle position setting method”, user manual will describe on subsequent chapter.



Knee-control switch function. Under the overlapping sewing and programmed sewing after turn on this function, use knee-control switch can shift sewing segment in turn in the edited pattern.



Back-tacking temporary cancel function. After setting start back-tacking or end back-tacking in current sewing pattern, if current temporary no need to back-tacking then can active this key, and sewing next back-tacking can cancel. And end back-tacking also can effective.



The program interrupt key. This key is used in the programmed sewing state. Under the programmed sewing state press this key, the current sewing program interruption it will not counted, after that tread the pedal machine will be free sewing according to the data of the sewing segment at the time of interruption. Cancel activation, the

program will continue.



Under the free sewing mode activate this key used for coiling bottom thread, at this time the upper and lower rollers not action.



Under the programming sewing activate this key, it will automatic stop machine after sewing is completed for current segment. If not activated, then the editing pattern will continuously sewing until the end of program.



Under the programmed sewing mode activated this key, then tread the pedal machine will be automatic sewing complete pattern.



Under the programmed mode activated this key, and use the “scroll key” to find the corresponding setting item, then can change the current sewing stitches for sewing segment.



Turn on the soft start function then can activated this key.



Free sewing, overlapping sewing and programmed sewing shift key. At the end of program or at the end of force trimming state, press this key can shift free sewing, overlapping sewing and programmed sewing mode.



Scroll key. Under the sewing mode can use this key to shift between different setting item. But the prerequisite is setting item need to be activated.

Function



Press this key on correspond position, parameter plus.



Press this key in correspond position, parameter minus.



Long press this key, it will enter to pattern editing mode. See the following section for detailed operation.



Long press this key, it will enter to parameter setting mode. See the following section for detailed operation.



Lock and unlock key. The previous icon indicates that the touch screen is locked. At this time, other keys on the touch screen are invalid except the unlock key, after clicking the unlock key, other keys on the touch screen resume function. The latter key icon indicates the unlock key, and in this state, the icons displayed on the LCD panel are all available. After manually clicking the unlock key, the touch screen will be locked. Or the automatic lock time is set in the parameter setting. After the time value is reached, the system will automatically lock.



Record stitches number and setting key. After counting stitches function turn on, this icon will display initial value. Setting method see following chapter.



Bottom thread display and setting key. This icon will display the remaining bottom thread when the bottom thread counter function is turned on. Setting method see the following chapter.



Return key.

2.2: Icon description



Upper roller icon



Lower roller icon



This icon corresponding number indicates current pattern no.



This icon corresponding number indicates current sewing speed.



This icon corresponding number indicates current sewing stitches.



This icon number indicates current sewing segment.

3: Basic operation

3.1 Free sewing



Figure 4: Free sewing interface - Roller value setting

3.1.1 Adjustment of roller value

As shown in the figure above, click or long press "+" in this interface, and the "-" key will change the current value of up and down rollers. The red box indicates the "up roller" adjustment key. The yellow box indicates the scroll wheel adjustment key. The interval between the upper and lower roller values shall not exceed 1.0 mm.

3.1.2 Start back-tacking setting




Figure 5: Free sewing screen - Start back-tacking setting



If you need to set up start back-tacking, activate the back-tacking key first . Then, click the scroll

key , shift settings interface, as shown above. Red box set "A" section, yellow box set "B" section, black box, set repeat number "R". R value is 2 and 4, when 2 indicates sewing AB, and as 4, it means sewing ABAB.



Figure 6: Free sewing interface - End back-tacking setting



If need to set end back-tacking, first to activated back-tacking key . And then click scroll key

, shift setting interface. Setting method same as the start back-tacking.

3.1.3 Speed setting




Figure 7: Free sewing interface - Speed setting



If need to setting speed, first to activated speed setting key . And then click scroll key



shift setting interface. Red box can setting start back-tacking speed, yellow box can setting end back-tacking speed, black box can setting speed of free sewing segment.

3.1.4 Needle position setting



Figure 8: Free sewing interface - Needle position angle setting

If need to use needle position function. First to setting the spindle parameter P12 “needle position function”



setting as 1, turn on this function. And then activated needle position setting key . Long press this key to

enter needle position angle setting interface. As shown in figure 8. Interface current display spindle shaft position, use the hand-wheel to turn the needle bar to requirement position, press “OK” key to save the current setting value,



and then press return key to turn back.

3.2 Overlapping sewing




Figure 9: Overlapping sewing interface - Scroll value setting

If you require to modify the data of one section, then click position of corresponding segment stitches number. At this time corresponding position display black background white word that indicates current segment is selected. After selected one section, the relevant keys and data in this page is belong current segment. As shown in the above figure, “A” segment is selected, at this time right side area display the upper and lower scroll value for “A” segment. Through red box “+”, “-” key, it can add or reduce the scroll value. Stitches and speed setting same as the free sewing, all need to activate the corresponding key then press scroll key to modify.



After key is activated, the system stops automatically after complete each segment sewing. Return the pedal to a neutral position and tread sewing position then can continue sewing next segment. If no need then



set this key as invalid state .



After key is activated, tread the pedal, system will automatically sewing all pattern till to finished.



If no need to set this key as invalid state .



Figure 10: Overlapping sewing interface- Needle position setting



If need to use needle position function in the overlapping sewing, please activated key. Press scroll

key shift to needle position setting page, use “+”, “-” key modify to require angle value. As require needle position value can through free sewing needle position angle setting page, by turn over hand-wheel, obverse current spindle shaft position to confirmation.

Noted: each section of the overlapping sewing can be set separately, including speed, stitches count, trimming, needle position, and whether trimming or not. Please confirm the pattern of sewing method and setting is same as your requirement or not before programming, otherwise it will make different sewing effects.



Figure 11: Overlap seam interface - Number of segments setting

How to use overlapping stitches: Section A represents the forward sewing part, and section B represents the backward sewing part. The number under the "SEG" character indicates that a total of several sections are sewn. For example, if SEG is 1, it means only the A segment is sewn, and if it is 2, it means the AB segment is sewn. 3

means ABA. And so on. A total of 8 segments can be set. The arrow in the red box can increase or decrease the number of segments.

3.2 Programmed sewing




Figure 12: Programmed sewing interface - Description

As shown in the above figure, in the programmed sewing interface red box indicates the current code of pattern. Right side blue box at the top of number indicates current pattern total segment. The below number indicates segment no. of currently displayed on the LCD. Under the programmed sewing finished, it can use in the red box "+" and "-" keys to select different patterns stored in the system. If the pattern selected has more than one segment, it can be selected by "+" and "-" in the blue box. Under the sewing interface, you can modify all the data except adding section, deleting section and circular sewing function. After modification, the parameters will be available.

It need to note the front two pattern in the programmed sewing, the pattern 1 and pattern 2 are fixed pattern can't to delete. Each pattern can add 3 segment. Each segment sewing is free sewing mode, after added multi-segment, it can through sewing machine head key, knee-control switch and LCD panel to shift between



multi-segments. Please activated key if you need to use sewing machine head keys or knee-control switch to shift between segments, otherwise the system will not perform shift action. Multi-segment can setting different stitches number. The following description is use LCD panel to shift different segment method. Such as below figure is no.1 pattern has been added as 3 segment.



Figure 13: Programmed sewing interface - Multi-segment shift



Use the LCD panel to shift different segment, at first need to activated key, then use “+”, “-” key in the red box to select require sewing segment.



Figure 14: Programmed sewing interface - Multi-segment shift

As shown in above figure is shift to the second segment interface, segment no is display 2nd segment, after

S -

number and selected segment number is same number 2. Only in this case, the segment shift succeed.



If not activated break key , after selected segment number, after **S -** number is different with segment number, at this time haven't shift the pattern data, just shift segment data page, sewing information not transmitted to control box.



Figure 15: Programmed sewing interface - Setting start back-tacking

On the programmed sewing, start back-tacking, end back-tacking setting method is similar as free sewing. The different is under programmed modem, it can't modify speed and repeat times for start back-tacking and end back-tacking. If modified this information need to enter program editing mode select corresponding pattern to edit.

4. Parameter setting

Long press key, enter to parameter setting interface.



Figure 16: Parameter selection interface

Parameter selection interface bottom right display software version information of operation panel and control box.

Take the 1st parameter as an example: after click “panel parameter”, enter to panel parameter setting interface.



Figure 17: Parameter setting interface

<No 01>

As shown above figure, click white key for turn left or turn right, interface will turn to previous or latter parameter setting interface, at the same time after No. Number will be change accordingly. After select the parameter item which want to modify, use right side “+” “-” key to modify the parameter value. After modified, click “OK” key to save. If not click “OK” key then to shift parameter item or exit setting, the parameter will not to save. Other parameter setting method same as this.

5. Program editing



After long press key, it will enter program editing catalogue page.



Figure 18: Program editing catalogue

5.1 Added pattern

Click “added pattern” item, display interface.



Figure 19: Added pattern

As shown above figure, in the P04 the 04 indicates it will add pattern code, click right side “+” key will added 4th pattern. After complete added, waiting add pattern number will automatic add 1 to became next waiting for add pattern, if no need to continue add then press return key to back.

5.2 Delete pattern

Click “delete pattern” item, display interface



Figure 20: Delete pattern



Use right “+”, “-”key to select waiting delete pattern. Then press key to delete pattern. No.1 and No.2 pattern can't delete.

5.3 Pattern editing

Click “select will need to edit pattern no” item, display interface.




Figure 21: Select waiting editing pattern

Press key to select need to editing pattern number. After select press key, to enter editing interface.

5.3.1 Editing method



Figure 22: Pattern editing method

Pattern editing method, it is similar with previous chapter introduction setting method in the sewing interface.

At first it need to consider the pattern require how many segment. If more than 1 segment, then need to add the

segment. At this time click key to shift segment added, delete page.






Figure 23: Adding delete segment

Press “+”, “-” key white font below of the “add segment”, delete segment. Press “+”, “-” key white font below of the “cycle sewing”, the pattern setting as the cycle sewing mode. **Noted: only after the segment have been set then can setting cycle sewing.**


After the segment have been set, press left “+”, “-”key below of the segment select need to editing segment.

For example: editing for one pattern of 3 segment, the one fist segment 6 stitches, the stitches length 3mm, start have start back-tacking, segment speed 2000. The second segment 8 stitches, the stitches length 3.5mm, segment speed 2100. The third segment 10 stitches, stitches length 4.0mm, segment speed 2200. Trimming and foot presser lift after end back-tacking.





Shift between each setting use scroll key . The 2nd segment and 3rd segment setting method is same as 1st segment.



It need to save pattern after pattern editing setting.

5.4 Pattern output to USB flash drive

Export the edited pattern on the current machine to the U disk. This operation can easily input the edited pattern to other unedited machines. The patterns that can be output start from the pattern number 3 on this machine to the maximum pattern number that has been edited. If no pattern is added, it cannot be output.

5.5 U disk pattern input to memory

Put the pattern In the U disk into the memory of the current machine. The pattern numbers will be sorted from the patterns that already exist on this machine.

Machine parameter description

1 Panel parameter

1.1 Panel backlight adjust: 30%~100%. Default: 50%

1.2 Panel Lock Time Adjust: 120 Sec, 180 Sec, 240 Sec, 300 Sec, OFF. Default: 120 Sec.

1.3 Tilt switch enable: ON/OFF. Default: ON.

1.4 Large stitch length disable: ON/OFF. Default: ON. (The stitch length can be adjusted to 7mm after closing)

2 Statistics function

2.1 Thread bobbin counter enable: ON/OFF. Default: OFF

2.2 Piecework counter enable: ON/OFF. Default: OFF

2.3 Machine lubrication tips enable: ON/OFF. Default: OFF

2.4 Bobbin thread unit value: 200~9999. Default: 3000

2.5 Piecework unit value: 0~9999. Default: 0.

2.6 Lubrication tips value: 50~1000. Default: 100 Unit: Hour

3 Tacking and back-tacking parameter

- 3.1 Start back-tacking speed: 700~1500. Default: 1500 Unit: Rpm
- 3.2 End back-tacking speed: 700~1500. Default: 1500 Unit: Rpm
- 3.3 Sewing back-tacking speed: 700~1500. Default: 1500 Unit: Rpm
- 3.4 Back-tacking break mode: 0~1. Default: 0
- 3.5 Action mode after start back-tacking: 0~2. Default: 0
- 3.6 Back-tacking speed mode 0~1. Default: 0
 - 0: Sewing at set speed
 - 1: Sewing at the pedal speed
- 3.7 Back-tacking start angle: 176~186. Default: 180

4 Pedal parameter

- 4.1 Pedal speed curve 3 Adjustment: 1~10. Default: 8
- 4.2 Pedal speed curve: 0~3. Default: 3
- 4.3 Pedal judgment time: 0~200. Default: 40

5 Thread trimming parameter

- 5.1 Trim speed: 20~400. Default: 200
- 5.2 Trim stage: 0~1. Default: 0
- 5.3 Trim start angle: 100~250. Default: 140
- 5.4 Trim end angle: 0~80. Default: 40
- 5.5 Thread tension start angle: 0~359. Default: 5
- 5.6 Thread tension end angle: 0~359. Default: 48
- 5.7 Trim solenoid duty: 25~100. Default: 80
- 5.8 Trim mode: Normal trim, Lockstitch trim. Default: Normal trim
- 5.9 Lockstitch trim direction: Forward, Backward. Default: Forward
- 5.10 Lockstitch trim stitch length: 1~10. Default: 3
- 5.11 Lockstitch trim stitch numbers: 1~3. Default: 1
- 5.12 First sew tension enable: ON/OFF. Default: OFF
- 5.13 First sew tension end angle: 100~359. Default: 200
- 5.14 Tension solenoid duty: 5~100. Default: 100

6 Presser foot parameter

- 6.1 Enable roller presser: ON/OFF. Default: ON

6.2 Roller presser slow down enable: ON/OFF. Default: OFF

6.3 Sew start delay time when presser down: 0~25. Default: 8

6.4 Presser lift holding time: 3~15. Default: 8

6.5 Presser solenoid duty: 10~40. Default: 20

6.6 Presser slowdown time: 20~200. Default: 50

7 Soft start parameter

7.1 Soft start enable: ON/OFF. Default: OFF

7.2 Soft start stitch numbers: 1~99. Default: 1

7.3 Soft start first stitch speed: 100~1800. Default: 600

7.4 Soft start second stitch speed: 100~2000. Default: 1000

7.5 Speed after the third stitch: 100~2200. Default: 1500

8 Segment sewing parameter

8.1 Up roller size:

(1): 25/70 D30

(2): 18/52 D30

(3): 20/58 D26

(4): 20/58 D28

(5): 20/84 D36

(6): 20/68 D28

(7): 23/70 D30

8.2 Auto run enable: 0~1. Default: 0

8.3 Auto run time: 2~6. Default: 3

8.4 Auto run stop time: 2~4. Default: 2

8.5 Feed angle: 95~115. Default: 100

8.6 Differential gap: 10~25. Default: 10

9 Main shaft parameter

9.1 Maximum speed: 1000~3000. Default: 2500

9.2 Minimum speed: 1000~3000. Default: 200

9.3 Positioning speed: 1000~3000. Default: 100

9.4 Accelerate factor: 1~100. Default: 20

9.5 Decelerate factor: 1~100. Default: 20
9.6 Motor boost enable: ON/OFF. Default: OFF
9.7 Motor boost setting: 1~15. Default: 1
9.8 Shaft motor reversal enable after thread trimming: ON/OFF. Default: OFF
9.9 Shaft motor reversal angle after thread trimming: 10~40. Default: 10
9.10 Shaft motor hold function: 0~2. Default: 0
9.11 Prevent the thread from falling out of the needle enable: ON/OFF. Default: OFF
9.12 Stitch length of prevent the thread from falling out of the needle: 1~10. Default: 3
9.13 Stitch numbers of prevent the thread from falling out of the needle: 1~3. Default: 1
9.14 Stitch placement enable: ON/OFF. Default: OFF
9.15 Patch stitch mode: 0~1. Default: 0
9.16 Angle of needle under cloth: 80~150. Default: 102
9.17 Angle of needle bar low position: 100~200. Default: 130
9.18 Angle of needle bar high position: 0~100. Default: 60

Error code list

1 Control box error code

3100 Software unauthorized

3101 Parameter out of range

Reinitialize parameter.

3110 Pedal setting error / or pedal malfunction

Pedal AD value is not correct.

3111 Encoder or datum point sensor malfunction or motor malfunction

Please check the spindle shaft is stuck or not, or encoder malfunction.

3112 Date error

Date process error, reset sewing parameter.

3113 Zero-position sensor error

Please check the spindle shaft is stuck or not, or encoder malfunction.

3114 Sewing machine head open

Machine head is turn over or machine head sensor angle of inclination malfunction.

3118 Solenoid malfunction

Please check the solenoid is short-circuit or not.

3119 spindle shaft abnormal

Spindle shaft stuck or encoder abnormal.

3120 Pendulum motor abnormal

Pendulum stuck or other caused can't rotate.

3121 Communication malfunction

It not received the panel return data.

3122 Communicate data verification error

The data received was wrong

3123 Spindle shaft drive abnormal

Spindle motor over-current.

3124 Pendulum drive abnormal

Pendulum motor over-current.

3125 Pattern transfer error

Pattern transfer error, communicate problem.

3126 Parameter transfer error

Parameter transfer error, communicate problem.

3127 Knee-control shift sewing failure

The panel no response when shift sewing segment.

3128 Pendulum position abnormal

The pendulum position is out of the normal range.

3129 Over-voltage

Supply voltage is too high.

3130 Under-voltage

Supply voltage is too low.

2 Panel error code

2.1 The control box can't find original point

Spindle shaft or pendulum can't find the original point. At first please check the spindle is running or not then check the pendulum.

Sewing with 2 different stitch lengths and retrieval via knee switch:

- » Go to „PSewing“
- » Press „Open Folder“
- » Press „P“ long
- » Press „Program A Dsn“
- » Now select the desired program number with the + button
- » Confirm with the green tick
- » Press „Open Folder“ again
- » For „INS“ enter the desired number of seam sections and confirm with „Open Folder“
- » For seam section 1, please enter the stitch length for the feed wheel and roller presser
- » Now use the left + - buttons to select the 2nd seam section
- » For seam section 2, please enter the stitch length for the feed wheel and roller presser
- » Activate thread trimming
- » Go to the „Return“ button at the top right
- » You will be asked to “Save Design?” And confirm with “YES”.
- » Go to the „Return“ button at the top right
- » Now activate the knee lever with the button



You can now call up between the different stitch lengths with the knee switch or the button on the machine head.



**POST BED COMPOUND FEED SEWING
MACHINE WITH STEP MOTOR**


PARTS MANUAL
零件手册

CONTENT 目录

A. Arm bed and its accessories 机壳部件.....	2
B. Presser bar parts 压杆部件.....	4
C. Needle bar holder parts 针棒座部件.....	6
D. Thread tension regulator parts 夹线调节器部件.....	8
E. Main shaft driving parts 主动轴传动部件.....	10
F. Needle feed parts 针送料部件.....	12
G. Presser foot lifting parts 压脚提升部件.....	14
H. Bobbin winder parts 绕线器部件.....	16
I. Bed plate feed parts for 2 needle 双针中座部件.....	18
J. Lower feed and clutch set parts 下送料及离合器部件	20
K. Oil lubrication parts 润滑部件.....	22
L. Hook parts (Left)旋梭勾线、剪线部件 (左)	24
M. Side bracket parts (Left)边座部件 (左)	26
N. Hook parts (Right)旋梭勾线、剪线部件 (右)	28
O. Side bracket parts (Right)边座部件 (右)	30
P. Side bracket parts (Short thread end)边座部件 (短线头)	32
Q. Thread trimming parts (Short thread end)剪线部件 (短线头)	34
R. Bed plate feed parts 单针中座部件.....	36
S. Thread trimming solenoid, thread releasing solenoid parts 剪线、松线电磁铁部件...	38
T. Thread trimming driving parts 剪线传动部件.....	40
U. Presser foot lifting solenoid parts 压脚提升电磁铁部件.....	42
V. Upper feed parts for 1 needle 上送料部件 (单针)	44
W. Upper feed parts for 2 needle 上送料部件 (双针)	46
X. Electric control, backstitch lever parts 电控及倒缝扳手部件.....	48
Y. Accessories 附件.....	50
Z1. Thread trimming mechanism(Large hook)剪线机构(大梭)	52
Z2. Right side bracket mechanism(Large hook)右边座机构(大梭)	54


A. Arm bed and its accessories 机壳部件

A. Arm bed and its accessories 机壳部件



B. Presser bar parts 压杆部件


B. Presser bar parts 压杆部件



C. Needle bar holder parts 针棒座部件


No.	Part No.	Name	名称	1 NEEDLE	2 NEEDLE
1	7.02.01.353	Thread take-up assy.	天秤组件	1	1
2		Thread take-up fixed pin	天秤固定销	1	1
3		Plastic stop ring	塑料挡圈	2	2
4		Needle bearing	滚针轴承	2	2
5		Thread take-up holder	天秤固定架	1	1
6		Thread take-up shaft bushing	天秤轴套管	1	1
7	7.02.15.049	Set screw	紧定螺钉 GB/T 80 M5×8	2	2
8		Screw	螺钉	1	1
9		Thread take-up lever	天秤杆	1	1
10		Bearing	轴承 624-2Z	1	1
11		Bearing	轴承 628/8-2Z	1	1
12	7.02.18.030	Elastic retaining ring	轴用弹性挡圈 GB/T 894.1 8	2	2
13		Thread path	线道	1	1
14	7.02.06.001	Thread take-up crank	天秤曲柄	1	1
15	7.02.05.005	Needle bar connector	针棒连接器	1	1
16	7.02.04.006	Needle bearing	滚针轴承 HK 1010	1	1
17	7.02.18.009	Washer	垫圈	1	1
18	7.02.05.006	Needle bar fixer	针棒固定器	1	1
19	7.02.15.066	Screw	螺钉 M5×10	1	1
20	7.02.16.011	Oil felt	油棉	1	1
21	7.02.12.001	Needle bar connector guide slot	针棒连接器导槽	1	1
22	7.02.15.021	Guide slot screw	导槽螺钉 M4×6	2	2
23	7.02.12.002	Needle bar guide slide block	针棒导引滑块	1	1
24	7.02.16.012	Oil felt	油棉	1	1
25	7.02.17.005	Oil felt holder	油棉压板	3	3
26	7.02.15.022	Oil felt pressing plate screw	油棉压板螺钉 M4×4.5	2	2
27	7.02.17.001	Fixed plate of needle bar holder	针棒座固定板		1
28	7.02.15.022	Fixed plate screw	固定板螺钉 M4		1
29	7.02.15.064	Set screw	紧定螺钉 M6×12		1
30	7.02.08.025	Bushing	套管		1
31	7.02.08.026	Bushing	套管		1
32	7.02.13.001	Needle bar holder	针棒座	1	1
33	7.02.10.012	Pin	锥销	1	1
34	7.02.03.007	Main shaft	针送主轴	1	1
35	7.02.09.001	Collar	定环	1	1
36	7.02.15.054	Set screw	紧定螺钉 M6×0.75×5	1	1
37	7.02.02.399	Needle holder	针馏(单针)	1	
38	7.02.15.862	Needle clamp screw	针夹螺钉	1	
39	7.02.14.112	Needle bar thread stand	针棒线挂	1	
40	7.02.18.002	Disk type washer	盘形垫圈	2	
41	7.02.04.010	Needle bearing	滚针轴承 K 15×19×17	2	
42	7.02.08.004	Bushing	套管	2	
43	7.02.08.024	Needle clamp bushing	针夹套管		1
44	7.02.15.040	Bushing screw	套管螺钉		1
45	7.02.02.007	Needle holder	针馏(双针)		1
46		Needle holder screw	针馏螺钉		2
47	7.02.03.018	Needle bar	针棒		1
48		Needle	机针	1	2
49		Vibrating needle stopper plate	摆针限位板	1	
50		Stopper plate screw	限位板螺钉	1	

C. Needle bar holder parts 针棒座部件




D. Thread tension regulator parts 夹线调节器部件

D. Thread tension regulator parts 夹线调节器部件




E. Main shaft driving parts 主动轴传动部件

E. Main shaft driving parts 主动轴传动部件




F. Needle feed parts 针送料部件

F. Needle feed parts 针送料部件




G. Presser foot lifting parts 压脚提升部件

G. Presser foot lifting parts 压脚提升部件




H. Bobbin winder parts 绕线器部件

H. Bobbin winder parts 绕线器部件




I. Bed plate feed parts for 2 needle 双针中座部件

I. Bed plate feed parts for 2 needle 双针中座部件




J. Lower feed and clutch set parts 下送料及离合器部件

J. Lower feed and clutch set parts 下送料及离合器部件



K. Oil lubrication parts 润滑部件



K. Oil lubrication parts 润滑部件



L. Hook parts (Left) 旋梭勾线、剪线部件 (左)


No.	Part No.	Name	名称	1 NEEDLE	2 NEEDLE
1	7.02.01.285	Hook assy.	旋梭组件		1
1-1		Bobbin case	旋梭壳组		1
1-2		Elastic gasket	阻尼弹片		1
1-3		Screw	螺钉		3
1-4		Screw	螺钉		1
1-5		Needle guard slice	护针片		1
1-6		Screw	护针片螺钉		2
2	7.02.15.038	Screw	旋梭螺钉 M5×20		1
3	7.02.21.385	Bobbin	锁芯		1
4	7.02.15.047	Screw	螺钉 M4		2
5	7.02.07.205	Driven gear	动刀传动齿轮		1
6	7.02.15.799	Screw (Long)	螺钉 (长) GB/T 70.1 M4×25		1
7	7.02.20.051	Thread trimming clamp plate	剪线夹线板		1
8	7.02.15.801	Screw	夹线板螺钉		1
9	7.02.20.052	Movable knife	动刀		1
10	7.02.15.973	Screw	动刀螺钉		1
11	7.02.03.342	Driven shaft	动刀转动轴		1
12	7.02.10.458	Eccentric pin	偏心销		1
13	7.02.15.433	Screw	定刀螺钉 M4×6		1
14	7.02.20.050	Fixed knife	定刀		1
15	7.02.15.063	Screw (Short)	螺钉 (短) GB/T 70.1 M4×10		1
16	7.02.01.352	Movable knife bracket	动刀架组件		1
17	7.02.10.370	Position pin	定位销		1
18	7.02.04.019	Bearing	平面轴承		1
19	7.02.04.018	Needle bearing	滚针轴承 K8×11×13		1
20	7.02.07.206	Gear	送料平面齿轮		1
21	7.02.15.054	Screw	齿轮螺钉 M6×0.75×5		1
22	7.02.15.247	Set screw	齿轮紧定螺钉 1/4×40×4		2
23	7.02.18.255	Elastic retaining ring	轴用弹性挡圈		1
24	7.02.18.256	Washer	垫圈		1
25	7.02.11.386	Oil guard plate	防油板		1
26	7.02.08.027	Bushing	釜轴中套管		1
27	7.02.04.113	Bearing	推力轴承 BTM14222.5		1
28	7.02.18.257	Washer	垫圈		1
29	7.02.04.020	Bearing	轴承 K14×17×10		2
30	7.02.01.356	Bushing	釜轴外套管		1
31	7.02.04.009	Needle bearing	滚针轴承 K8×11×10		1
32	7.02.01.288	Thread distributing claw	分线勾		1
33	7.02.15.420	Screw	螺钉 GB/T 65 M4×6		1
34	7.02.01.289	Thread distributing claw bracket	分线勾座		1
35	7.02.16.300	Seal ring	密封圈		1
36	7.02.11.385	Oil supply plate	旋梭供油板		1
37	7.02.15.577	Screw	螺钉 GB/T 70.1 M4×12		1
38	7.02.16.303	Oil supply valve	旋梭供油阀组件		1
39	7.02.15.022	Screw	螺钉 M4×4.5		1
40	7.02.16.047	Oil tube	油管		1
41	7.02.03.340	Shaft	旋梭轴		1

L. Hook parts (Left) 旋梭勾线、剪线部件（左）



M. Side bracket parts (Left) 边座部件 (左)


M. Side bracket parts (Left) 边座部件 (左)



N. Hook parts (Right) 旋梭勾线、剪线部件 (右)


No.	Part No.	Name	名称	1 NEEDLE	2 NEEDLE
1	7.02.01.285	Hook assy.	旋梭组件	1	1
1-1		Hook-top	梭头体	1	1
1-2		Screw	板式弹簧螺钉	2	2
1-3		Spring	板式弹簧	1	1
1-4		Elastic gasket	阻尼弹片	1	1
1-5		Bobbin case base	梭宛	1	1
1-6		Screw	螺钉	3	3
1-7		Hook gib	内梭头舌	1	1
1-8		Bobbin case	梭壳	1	1
1-9		Screw	螺钉	1	1
1-10		Needle guard slice	护针片	1	1
1-11		Screw	护针片螺钉	2	2
2	7.02.15.038	Screw	旋梭螺钉 M5×20	1	1
3	7.02.21.385	Bobbin	梭心	1	1
4	7.02.15.047	Screw	螺钉	2	2
5	7.02.07.205	Driven gear	动刀传动齿轮	1	1
6	7.02.15.799	Screw (Long)	螺钉(长) GB/T 70.1 M4×25	1	1
7	7.02.20.051	Thread trimming clamp plate	剪线夹线板	1	1
8	7.02.15.801	Screw	夹线板螺钉	1	1
9	7.02.20.052	Movable knife	动刀	1	1
10	7.02.15.973	Screw	动刀螺钉	1	1
11	7.02.03.342	Driven shaft	动刀传动轴	1	1
12	7.02.10.458	Eccentric pin	偏心销	1	1
13	7.02.15.433	Screw	定刀螺钉 M4×6	1	1
14	7.02.20.050	Fixed knife	定刀	1	1
15	7.02.15.063	Screw (Short)	螺钉(短) GB/T 70.1 M4×10	1	1
16	7.02.01.352	Movable knife bracket	动刀架组件	1	1
17	7.02.10.370	Restrict pin	限位销	1	1
18	7.02.04.019	Bearing	平面轴承	1	1
19	7.02.04.018	Needle bearing	滚针轴承	2	2
20	7.02.18.251	Elastic retaining ring	轴用弹性挡圈 GB/T 894.1 21	1	1
21	7.02.16.303	Oil supply valve	旋梭供油阀组件	1	1
22	7.02.15.022	Fixed screw	供油阀固定螺钉	1	1
23	7.02.16.047	Oil tube	油管	1	1
24	7.02.03.340	Shaft	釜轴	1	1
25	7.02.11.385	Oil supply plate	旋梭供油板	1	1
26	7.02.16.300	Seal ring	密封圈	1	1
27	7.02.01.289	Thread distributing claw bracket	分线勾座	1	1
28	7.02.15.420	Screw	螺钉 GB/T 65 M4×6	1	1
29	7.02.01.288	Thread distributing claw	分线勾	1	1
30	7.02.15.577	Screw	螺钉 GB/T 70.1 M4×12	1	1
31	7.02.18.252	Washer	垫圈	1	1
32	7.02.11.386	Oil guard plate	防油板	1	1
33	7.02.08.392	Bushing	釜轴套管	1	1
34	7.02.09.080	Bushing collar	釜轴套管紧圈	1	1
35	7.02.15.054	Screw	螺钉 M6×0.75×6	2	2
36	7.02.06.279	Thread trimming crank	剪线曲柄	1	1
37	7.02.15.056	Crank screw	曲柄螺钉 GB/T 74 M5×5	1	1
38	7.02.15.063	Set screw	紧定螺钉 GB/T 70.1 M4×10	1	1

N. Hook parts (Right) 旋梭勾线、剪线部件 (右)



0. Side bracket parts (Right) 边座部件 (右)


0. Side bracket parts (Right) 边座部件 (右)



P. Side bracket parts (Short thread end) 边座部件(短线头)


No.	Part No.	Name	名称	1 NEEDLE	2 NEEDLE
1	7.02.02.392	Hook assy.	旋梭组件	1	
2	7.02.15.038	Screw	旋梭螺钉	1	
3	7.02.21.385	Bobbin	梭芯	1	
4	7.02.16.300	Sealing ring	密封圈	1	
5	7.02.11.385	Oil supply plate	旋梭供油板	1	
6	7.02.03.340	Shaft	旋梭轴	1	
7	7.02.04.019	Bearing	推力轴承	1	
8	7.02.04.018	Needle bearing	滚针轴承	2	
9	7.02.08.600	Bushing	釜轴套管	1	
10	7.02.02.662	Thread distributing claw	分线勾	1	
11	7.02.15.420	Screw	螺钉	1	
12	7.02.02.663	Thread distributing claw bracket	分线勾座	1	
13	7.02.15.577	Screw	螺钉	1	
14	7.02.02.661	Post cap	釜盖	1	
15	7.02.15.973	Screw	螺钉	2	
16	7.02.11.650	Cover plate	边盖板	2	
17	7.02.15.973	Screw	螺钉	8	
18	7.02.10.590	Adjusting pin	调整销	1	
19	7.02.15.056	Set screw	紧定螺钉	1	
20	7.02.15.057	Set screw	釜轴套管紧定螺钉	1	
21	7.02.13.501	Side bracket (Right)	右边座	1	
22	7.02.15.965	Screw	螺钉	2	
23	7.02.18.003	Washer	垫片	2	
24	7.02.17.420	Elastic gasket	釜盖弹片	1	
25	7.02.15.433	Screw	螺钉	1	
26	7.02.16.559	Rubber plug	橡胶塞	1	
27	7.02.11.660	Thread guide	拦线板	1	
28	7.02.15.1144	Screw	拦线板螺钉	2	
29	7.02.11.661	Thread guide fixed plate	拦线板固定板	1	
30	7.02.15.674	Screw	螺钉	2	
31	7.02.04.110	Ball bearing	滚珠轴承	1	
32	7.02.18.250	Elastic retaining ring	孔用弹性挡圈	1	
33	7.02.16.560	Oil qty.regulating valve assy.	油量调节阀组件	1	
34	7.02.15.022	Screw	螺钉	1	
35	7.02.16.047	Oil tube	油管	1	
36	7.02.09.115	Collar	紧圈	1	
37	7.02.15.054	Screw	螺钉	4	
38	7.02.07.011	Gear (Small)	齿轮(小)	1	
39	7.02.07.012	Gear (Large)	齿轮(大)	1	
40	7.02.15.050	Screw	螺钉	2	

P. Side bracket parts (Short thread end) 边座部件 (短线头)




Q. Thread trimming parts (Short thread end) 剪线部件 (短线头)

Q. Thread trimming parts (Short thread end) 剪线部件 (短线头)




R. Bed plate feed parts 单针中座部件

R. Bed plate feed parts 单针中座部件




S. Thread trimming solenoid, thread releasing solenoid parts 剪线、松线电磁铁部件




T. Thread trimming driving parts 剪线传动部件

T. Thread trimming driving parts 剪线传动部件




U. Presser foot lifting solenoid parts 压脚提升电磁铁部件

U. Presser foot lifting solenoid parts 压脚提升电磁铁部件




V. Upper feed parts for 1 needle 上送料部件 (单针)

V. Upper feed parts for 1 needle 上送料部件 (单针)




W. Upper feed parts for 2 needle 上送料部件 (双针)

W. Upper feed parts for 2 needle 上送料部件 (双针)




X. Electric control, backstitch lever parts 电控及倒缝扳手部件

X. Electric control, backstitch lever parts 电控及倒缝扳手部件



Y. Accessories 附件


Y. Accessories 附件



Z1. THREAD TRIMMING MECHANISM(Large hook)

No.	Part No.	Fig. No.	Name	Qty	Remark
1	7.02.19.391	AG2810-01	Thread trimming solenoid	1	
2	7.02.15.797	AG2110-02	Screw	2	M4×6
3	7.02.11.387	AG2110-03	Fixed plate	1	
4	7.02.15.803	AG2110-04	Fixed plate screw	2	GB/T70.1 M5×10
5	7.02.05.528	AG2810-16	Thread trimming solenoid joint	1	
6	7.02.11.601	AG2810-15	Solenoid connecting plate	1	
7	7.02.10.546	AG2810-17	Solenoid connecting pin	1	
8	7.02.18.031	RE000040	Split retaining ring	2	GB/T896 4
9	7.02.10.367	AG2110-14	Connecting lever pin	1	ø6×21
10	7.02.15.056	ZMH05002	Screw	2	M5×5
11	7.02.05.525	AG2810-08	Thread trimming vibrating lever assy.	1	
12	7.02.17.490	AG2810-18	Spring	1	
13	7.02.03.341	AG2110-09	Thread trimming vibrating lever shaft	1	
14	7.02.15.908	GL04-14-1	Screw	1	
15	7.02.13.293	AG2110-11	Thread trimming vibrating lever seat	1	
16	7.02.15.798	AG2110-12	Screw	2	M5×30
17	7.02.10.369	AG2110-19	Connecting lever pin	1	ø6×15.5
18	7.02.05.526	AG2810-13	Thread trimming connecting lever	1	
19	7.02.15.1091	AG2810-19	Screw	1	
20	7.02.06.471	AG2810-20	Thread trimming crank	1	
21	7.02.15.053	ZMJ05002	Screw	1	GB/T70.1 M5×12
22	7.02.06.470	AG2810-06	Thread trimming cam	1	
23	7.02.15.050	ZMH06002	Screw	2	M6×0.75×8
24	7.02.09.165	AG2810-07	Cam gap ring	1	
25	7.02.08.010	J4321-0A	Bearing bushing (left)	1	
26	7.02.15.056	ZMH05002	Screw	2	M5×5
27	7.02.04.012	BB6202ZZ	Bearing	1	6202-2ZNR
28	7.02.13.451	AG2810-22	Fixed knife seat	1	
29	7.02.15.1092	AG2810-23	Screw	2	GB/T70.1 M4×6
30	7.02.20.083	AG2810-25	Thread guard plate	1	
31	7.02.20.080	AG2810-26	Fixed knife	1	
32	7.02.15.1093	AG2810-27	Screw	2	
33	7.02.20.081	AG2810-29	Thread tension plate	1	
34	7.02.15.1094	AG2810-30	Screw	1	
35	7.02.20.082	AG2810-31	Movable knife	1	
36	7.02.15.1095	AG2810-32	Screw	1	
37	7.02.13.452	AG2810-33	Movable knife seat	1	
38	7.02.15.056	ZMH05002	Screw	2	M5×5
39	7.02.09.166	AG2810-38	Collar	1	
40	7.02.15.1096	AG2810-39	Screw	2	M4×3
41	7.02.03.506	AG2810-35	Movable knife shaft	1	
42	7.02.08.544	AG2810-36	Movable knife shaft bushing	1	
43	7.02.15.047	ZMH04001	Screw	1	M4×4

Z1. THREAD TRIMMING MECHANISM(Large hook)



Z2. RIGHT SIDE BRACKET MECHANISM(Large hook)

No.	Part No.	Fig. No.	Name	Qty	Remark
1	7.02.13.45001	AG2808-16	Single needle side bracket	1	
2	7.02.15.965		Screw	2	
3	7.02.18.003		Washer	2	
4	7.02.04.110	AG2108-11	Ball bearing	2	6001-2Z
5	7.02.18.250	AG2108-15	Elastic retaining ring	2	28
6	7.02.11.60001	AG2808-19	Side cover	2	
7	7.02.15.973		Screw	8	
8	7.02.02.590	AG2808-21	Post cap assy.	1	
9	7.02.15.973		Screw	2	
10	7.02.17.350	AG2108-23	Spring plate	1	
11	7.02.15.433		Screw	1	
12	7.02.10.011		Adjusting pin	1	
13	7.02.15.056		Screw	1	
14	7.02.16.514	AG2809-51	Hook oil supply valve assy.	1	
15	7.02.15.022		Screw	1	M4×4.5
16	7.02.16.047		Oil tube	1	
17	7.02.02.591	AG2809-01	Hook assy.	1	
18	7.02.21.567	AG2809-02	Bobbin	1	
19	7.02.15.1090	AG2809-03	Screw	1	
20	7.02.03.505	AG2809-04	Hook shaft	1	
21	7.02.04.200	AG2809-05	Needle bearing	1	K10×13×13
22	7.02.18.410	AG2809-06	Washer	2	
23	7.02.04.100		Ball	13	2.5
24	7.02.02.592	AG2809-11	Rotating hook opener	1	
25	7.02.08.540	AG2809-12	Rotating hook opener eccentric bracket	1	
26	7.02.08.541	AG2809-13	Rotating hook opener bracket	1	
27	7.02.15.047	ZMH04001	Screw	1	M4×4
28	7.02.10.545	AG2809-15	Adjusting pin	1	
29	7.02.15.047	ZMH04001	Screw	1	M4×4
30	7.02.12.320	AG2809-17	Slide block	1	
31	7.02.08.542	AG2809-18	Bushing (Upper)	1	
32	7.02.08.543	AG2809-19	Bushing (Lower)	1	
33	7.02.15.064	ZMH06005	Screw	2	GB/T70.1 M6×12
34	7.02.04.009	BN081110	Needle bearing	1	K 8×11×10
35	7.02.09.115	91-175 328-92	Retaining ring	1	
36	7.02.15.054	ZMH06007	Screw	2	M6×0.75×5
37	7.02.07.011	J4025-0A	Gear (Small)	1	
38	7.02.15.054	ZMH06007	Screw	2	M6×0.75×5
39	7.02.07.012	J4026-0A	Gear (Large)	1	
40	7.02.15.050	ZMH06002	Screw	2	M6×0.75×8
41	7.02.09.007	J4014-0A	Collar	1	
42	7.02.15.054	ZMH06007	Screw	2	M6×0.75×5

Z2. RIGHT SIDE BRACKET MECHANISM(Large hook)

