

GLOBAL

Our experience. Your success

LP 8970- E - SERIES

MANUAL



1. Safety

1.01 Safety symbols



Danger!
Points to be observed



Danger of injury for operating and specialist personnel !

Caution

Do not operate without finger guard and safety devices.
Before threading, changing bobbin and needle, cleaning etc switch off main switch.

1.02 Important points for the user

- This Instruction Manual is a component of the machine and must be available to the operating personnel at all times.
- The Instruction Manual must be read before operating the machine for the first time.
- The operating and specialist personnel must be instructed in the safeguards of the machine and safe work methods.
- It is the duty of the user to operate the machine in perfect running order.
- It is the obligation of the user to ensure that none of the safety mechanisms are removed or deactivated.
- It is the obligation of the user to ensure that only authorized persons operate and work on the machine.

Safety

1.03

Danger



A working area of 1 meter is to be kept free both in front of and behind the machine in operation so that the machine is always easily accessible.




Never reach into the sewing area while sewing! Danger of injury by the needle!



Never leave objects on the table while adjusting the machine settings! Objects can become trapped or be slung away! Danger of injury!



Do not operate the machine without support 1! Danger due to top-heavy sewing head! Machine can tip over backwards when tilted!





Switch the machine off before tilting it backwards!
Danger of injury if the machine is started accidentally!



Do not operate the machine without its take-up-lever guard **2**!
Danger of injury due to the motion of the take-up lever!



On machines with thread lubricator, only operate the machine with the eye guard **3** lowered! The eye guard **3** protects the eyes from oil particles from the thread lubrication!



Do not operate the machine without belt guard **4**!
Danger of injury by rotating drive belt!



Do not operate the machine without tilt lock **5**!
Danger of crushing between sewing head and table top!

Specifications

2

Specifications

Stitch type.....301(lockstitch)
Stitch length
Singl needle.....1.3-7mm
Double needle.....1.3-4.8mm
Clearance under roller presser.....7mm
Clearance width.....245mm
Clearance height.....115mm
Post heighe.....180mm

Sewing head dimensions

length.....approx.615mm
Width.....approx.240mm
Height(above table).....approx.500mm
Bedplate dimensions.....518x177mm

Max.speed

Singl needle.....2500spm
Double needle.....2000spm

Connection data

Operating voltage.....230V \pm 10%, 50/60Hz
Max.power consumption.....1.2KVA

Net weight of sewing head.....approx.61kg

Gross weight of sewing head.....approx.71kg

Subject to alteration


Model

LP 8971

LP 8974

3 Controls

3.01 Pedal




0= Neutral position

1= Sewing

2= Raiser roller presser


3= Trim sewing threads (on machines with-D..)

3.02 Lever for lifting roller presser



- The roller presser can be raised by turning lever 1.

3.03 Knee lever




- The roller presser can be raised by pressing the knee lever 1 in the direction of the arrow.

Controls

3.04


Key for setting stitch length



- The stitch length is set by pressing key 1 and turning the balance wheel.

3.05

Swing out roller presser



- When the roller presser is raised, it can be swung out by pulling it lightly downwards.

Installation and commissioning

4

Installation and commissioning



The machine must only be installed and commissioned by qualified personnel!
All relevant safety regulations must be strictly adhered to!



If the machine is delivered without a table, be sure to use a stand and table top that can hold the weight of the machine with its motor.
It is very important to ensure that the stand of the machine is firm and steady, also during sewing.


4.01 Installation

The site where the machine is installed must be provided with suitable connections for electric current.
It must be ensured that the standing surface of the machine site is firm and horizontal, and that sufficient lighting is provided for.



For packing and transportation reasons the table top is in the lowered position. The table height is adjusted as described below.


Adjusting the table height



- Loosen screws **1** and **2** and set the table height as required.
- Firmly tighten screw **1**.
- Set the required pedal position and tighten screw **2**.


Installation and commissioning

4.02 Fitting the reel stand



- Fit the reel stand as shown in Fig.
- Afterwards insert the stand in the hole of the table top and secure it with the nuts provided.

4.02.01 Fitting the tilt lock



Maschine ausschalten!
Verletzungsgefahr durch unbeabsichtigtes
Anlaufen der Maschine!

- Die im zubehör befindliche kippsicherung 1 mit schraube 2 anschrauben.



Maschine nicht ohne kippsicherung 1
betreiben! Sicherung 1 betreiben!
Quetschgefahr zwischen oberteil und
tischplatte!

4.03 Commissioning


- Check the machine, particularly the electrical wiring for any damage.
- Clean the machine thoroughly and then oil it or fill oil in.
- Have a mechanic check whether the motor of the machine can be operated with the available power supply, and that the motor is correctly connected in the junction box. If there are any discrepancies, the machine **must not be operated under any circumstances**.



The machine only be connected to an earthed socket!

- When the machine is running, the balance wheel must turn towards the operator. If it does not, the motor connection must be changed by a mechanic.
- Machines with pneumatic equipment must be connected to the compressed air supply. The pressure gauge should indicate a pressure of 6 bar. If necessary, adjust to the correct setting (see **Chapter 6.01 Checking adjusting the air pressure**).

4.04 Tilted work base



4.05 Tilted work base



Preparation



All instructions and regulations in this Instrution Manual must be observed .
Special attention must be paid to all safety regulations!




All setting-up work must only be carried out by personnel with the appropriate training. For all setting-up work the machine must be disconnected from its power supply by turning off the on/off switch, or removing the plug from the electric power socket.

5.01

Inserting needle on model



Switch the machine off! Danger of injury if the machine is started accidentally!



Only use needles of system **134**

- Raise the roller presser **1** and swing it out
- Loosen screw **2** and insert the needles as far as possible. The long groove must face to the **left** on model LP 8971
- Tighten screw **2** and swing roller presser **1** back to position.



The Choice of needle depends on the model of the machine and the thread and material used .

Preparation

5.02 Winding the bobbin thread; adjusting the primary thread tension



- Place an empty bobbin **1** into bobbin winder spindle **2**.
- Thread the bobbin as shown in **Fig.** And wind it clockwise around bobbin **1** a few times
- Switch on the bobbin winder while pressing bobbin winder spindle **2** and lever **3**.




The bobbin is filled up during sewing.

- The thread tension of bobbin **1** can be adjusted by knurled screw **4**.
- The bobbin winder stops automatically when bobbin **1** is full.


If the thread is wound unevenly:

- Loosen nut **5**.
- Turn thread guide **6** accordingly.
- Tighten nut **5**.



5.03 Removing/Inserting the bobbin case

Switch the machine off! Danger of injury if the machine is started accidentally!




Removing the bobbin case:

- Open the post cap.
- Raise latch **1** and remove bobbin case **2**.

Inserting bobbin case:

- Insert bobbin case **2**.
- Close the latch and close the post

5.04 Threading the bobbin case/Adjusting the bobbin thread tension



- Insert the bobbin into the bobbin case **1**.
- Pass the thread through the slot under spring **2**.
- Pass the thread through the notch.
- Adjust the thread tension by turning screw **3**.



When the thread is pulled, the bobbin must rotate in the direction of the arrow.

Preparation


5.05 Threading the needle thread and regulating its tension on model LP 8971



Switch the machine off!
Danger of injury if the machine is started accidentally!




- Tilt up the eye guard 1.
- Thread the needle thread as shown in **Fig.**
- Adjust the needle thread tension by turning milled screw 2.



5.06 Setting the stitch length



- Press key 1 and at the same time turn the balance wheel until the stitch setter clicks into position.
- Hold down key 1 and turn the balance wheel to and fro until the stitch length required is shown on the scale 2 opposite the bottom edge 3 of the belt guard recess.



Care and Maintenance

6


Care and Maintenance

Clean.....	daily, more frequently if in continuous operation
Oil level (thread lubrication/hook lubrication)	daily, before use
Oil the hook.....	daily, before use
Lubricate the bevel gears.....	once a year
Check/adjust air pressure.....	daily, before use
Clean air filter of air filter/lubricator.....	when required



These maintenance intervals are calculated for the average running time of a single shift operation. If the machine is operated more than this, shorter intervals are recommended.

6.01 Checking and adjusting the air pressure (on the pneumatic machine)




- Before operating the machine, always check the air pressure on gauge 1.
- Gauge 1 must show a pressure of **6 bar**.
- If necessary adjust to this reading.
- To do so, pull knob 2 upwards and turn it so that the gauge shows a pressure of **6 bar**.

Care and Maintenance

6.02 Clean the air filter of the air-filter/lubricator (on the pneumatic machine)



Switch the machine off!
Disconnect the air hose at the air-filter/lubricator.



Draining water bowl 1:

- Water bowl 1 drains itself automatically when the compressed-air hose is disconnected from the air-filter/lubricator.

Cleaning filter 2:

- Unscrew water bowl 1.
- Take out filter 2.
- Clean filter 2 with compressed air or isopropyl alcohol.
- Screw in filter 2 and screw on water bowl 1.


6.03 Cleaning

Clean the hook, hook compartment and toothed wheel 3 every day, several times if in continuous use

Switch the machine off!

Danger of injury if the machine is started accidentally!

Care and Maintenance




- Bring the needle bar to its highest position.
- Open the post cap and remove the bobbin case cap and the bobbin.
- Unscrew hook gib 1.
- Turn the hand wheel until the point of bobbin case 2 penetrates into the groove of the hook race approx. 5mm.
- Remove bobbin case 2.
- Clean the hook race with paraffin.
- When inserting the bobbin case 2, ensure that the horn of the bobbin case 2 engages in the groove of the needle plate.
- Screw hook gib 1 back on and close the post cap.

6.04 Oiling the hook




Switch the machine off!
Danger of injury if the machine is started accidentally!



- Pour **1-2 drops** of oil into hole 1 of the hook gib daily.
- Before commissioning the machine, and after long periods out of operation, pour a few drops of oil into the hook race (see arrow).

6.05 Oil bowl for hook lubrication



Check the oil level before each use. There must always be oil in reservoir 1.

If required refill oil through hole.




Use only oil with a mean viscosity of $22.0\text{mm}^2/\text{s}$ at 40°C and a density of $0.865\text{g}/\text{cm}^3$ at 15°C .



6.06 Filling the oil reservoir of the thread lubrication unit



Control the oil level before each use.
There must always be oil in the reservoir 1.



- If necessary, fill oil up to mark through hole

We recommend thread lubricating oil .

Care and Maintenance

6.07 Lubricating the bevel gears

Switch the machine off!
Danger of injury if the machine is started accidentally!

- All bevel gears must be supplied with new grease once a year.
- Tilt the sewing head back onto the support.



Fig. shows the bevel gears of the


- Apply grease to all the tooth flanks and the rack (see arrows).
- To set the sewing head upright, press tilt lock 1 backwards and set the sewing head upright using both hands.



Use both hands to set the sewing head upright!
Danger of crushing between the sewing head and the table top!



We recommend sodium grease with a dripping point of approx. 150°C.



7

Adjustment



Unless stated otherwise, during all adjustment work the machine must be disconnected from electric and pneumatic power supply!
Danger of injury if the machine is started accidentally!

7.01

Notes on adjustment

- All following adjustment are based on a fully assembled machine and may only be carried out by expert staff trained for this purpose.
- Machine covers, which have to be removed and replaced to carry out checks and adjustments, are not mentioned in the text.
- The order of the following chapters corresponds to the most logical work sequence for machines which have to be completely adjusted. If only specific individual work steps are carried out, both the preceding and following chapters must be observed.
- Screws, nuts indicated in brackets () are fastenings for machine parts, which must be loosened before adjustment and tightened again afterwards.

7.02

Tools, gauges and other accessories

- 1 set of screwdrivers with blade widths from 2 to 10 mm
- 1 set of open ended wrenches with opening sizes from 7 to 13 mm
- 1 set of allen keys from 1.5 to 6mm
- 1 clamp
- 1 metal ruler
- 1 gauge
- Sewing thread and test material

Adjustment

7.03 Adjusting the basic machine


7.03.01 Needle position in sewing direction on the LP 8971

Requirement

With the stitch length set at its minimum, the needle should be positioned in the centre of the needle hole, as seen in the direction of sewing.



- Set the minimum stitch length.
- Adjust needle bar (screw 1) according to the **Requirement**.




7.03.02 Preliminary adjustment of the needle height

Requirement

When the needle bar is at top dead centre, there must be a clearance of approx. 21 mm between the needle point and the needle plate.



- Adjust needle bar 1 (screw 2). Without turning it, according to the Requirement.



3. The needle guard **6** must touch the needle lightly.


Adjustment



- Loosen screw **1**, **2**, **3**, **4** and **5**.
- Bring needle bar to **2.0 mm** past bottom dead centre.
- Set hook point at needle centre, making sure that the needle is not deflected by needle guard **6**.
- Adjust needle height according to **Requirement 2**.
- Adjust hook post according to **Requirement 1** and tighten screw **4**.
- Making sure that there is some play in the bevel gear, tighten screws **2**.
- With retaining collar **7** touching bevel gear **8** tighten screws **1**.
- Adjust needle guard **6** (screw **9**) according to **Requirement 3**.



When the hook is changed, make sure that the markings **10** and **11** are both on one side.



Adjustment


7.03.04 Needle position crosswise to sewing direction on the LP 8971

Requirement

As seen crosswise to the sewing direction, the needle must penetrate in the centre of the needle hole.



- Adjust feed wheel post 1 (screws 2, 3 and 4) according to the Requirement.




7.03.05 Height and stroke of the bobbin case opener

Requirement

1. The top edges of the bobbin case opener **1** and bobbin case **3** should be on one level.
2. when the bobbin case opener **1** has deflected the bobbin case to its furthest point, the catch of the bobbin case should be from **0.3** to **0.5 mm** from the back edge of the needle plate recess.



- Adjust bobbin case opener **1** (screw **2**) in accordance with **Requirement 1**.
- Turn the balance wheel until the bobbin case opener has deflected the bobbin case to its furthest point.
- Adjust bobbin case opener **1** (screw **2**) in accordance with **Requirement 2**.



On the LP 8974 these adjustments must be repeated on the right post.
Depending on the thread size, a variation of the setting in Requirement 2 is permitted.

Adjustment


7.03.06 Height of the feed wheel on the LP 8974

Requirement

1. when pressure is applied to the feed wheel **4**, it should protrude from the needle plate by tooth height (approx. **0.8 mm**).
2. when no pressure is applied to the feed wheel **4**, it should have a vertical play of approx. **0.3 mm**.



- Swing out the roller presser
- Loosen screws **1** and **2** (two screws each).
- Adjust drive wheel **3** according to **Requirement 1**, taking care to see that the teeth of drive wheel **3** and feed wheel **4** lock into each other properly.
- Tighten screws **1**.
- Adjust guide **5** according to **Requirement 2** and tighten screws **2**.




7.03.07 Height of the feed wheel on the

Requirement

Feed wheel should protrude from the needle plate by tooth height (appro. **0.8 mm**).



- Swing out the roller presser
- Loosen screws 1.
- Adjust eccentric 3 (fastening screw accessible through hole 2) according.
- Tighten screws 1.



Adjustment


7.03.08 Stitch length control eccentric

Requirement

When the needle (with maximum stitch length set), coming from top dead centre, is **3 mm** above the needle plate, the crank **3** must have reached its front point of reversal.



- Set the maximum stitch length.
- Turn stitch length control device **1** (screws **2**) according to **Requirement**.




7.03.09 **Stitch length scale disk**

Requirement

When the stitch length control device is locked in position, and the maximum stitch length is set, the marking line of the highest number on the scale disk **1** must be opposite the lower edge **3** of the belt guard recess.



- Set the maximum stitch length.
- Turn the scale disk **1** according to the **Requirement**.



Adjustment


7.03.10 Shaft crank to feed wheel drive

Requirement

When the maximum length is set, the linkage rod **3**, or linkage rods **3** and **4** on the model LP 8971 must be able to move freely when the balance wheel is turned.



- Set the maximum stitch length.
- Twist or shift the shaft crank **1** (screw **2**) according to the **Requirement**.




7.03.11 Shaft crank to roller presser drive

Requirement

When the maximum stitch length is set, the linkage rods **3** and **4** must be able to move freely at their left and right point of reversal when the balance wheel is turned.



- Set the maximum stitch length
- Twist or shift the shaft crank **1** (screw **2**) according to the **Requirement**.



Adjustment


7.03.12 Clearance between roller presser and feed wheel

Requirement

When the presser bar lifter is raised, the clearance between the roller presser and the feed wheel must be **7 mm**.



- Raise the presser bar lifter.
- Adjust the presser bar **1** (screws **2**) according to the **Requirement**. Make sure that the roller presser is parallel to the feed wheel.



7.03.13 Roller presser


Requirement

When the roller presser **1** is touching the feed wheel **5** it must:

1. be parallel to feed wheel **5**, as seen in the direction of sewing.
2. be in the centre of the needle (on model 8974 the left needle), as seen in the direction of sewing.
3. be as near as possible to the needle (on model 8974 the left needle), as seen crosswise to the direction of sewing.



- Raise the roller presser.
- Always observe **Requirement 1** for subsequent adjustments.
- Adjust roller presser **1** (screw **2**) according to **Requirement 2**.
- Lower roller presser **1** to rest on feed wheel **5**.
- Adjust roller presser bracket **3** (screw **4**) according to **Requirement 3**.



When sewing very tight curves, the roller presser **1** must be moved a little towards the operator.

Adjustment

7.03.14 Stitch length on stitch length scale


Requirement

When the stitch length is set at “3” , and after the needle has entered a strip of leather **11 times**, the total length from the first to last needle penetration must be **30 mm**.



- Set stitch length “3” .
- By turning the balance wheel, let the needle enter **11 times** and measure the total length.
- Adjust clamp **1** (screw **2**) according to the **Requirement**.

Clamp **1** must not be positioned diagonally to the rock shaft!



7.03.15 Synchronization of roller presser and feed wheel

Requirement


After **30 needle penetrations** in a strip of leather the total length from the first to the last penetration should be the same, both in the lower and the upper leather layer.



- Set stitch length "3" .
- By turning the balance wheel, let the needle enter **30 times**.
- Compare the total sewn length of the lower and upper leather layer.
- Adjust clamp 1 (screw 2) according to the **Requirement**.



Clamp 1 must not be positioned diagonally to the rock shaft.



Adjustment

7.03.16 Retainer(only on 8974)


Requirement

The retainer **1** must:

1. be as close as possible to the needle, as seen in the direction of sewing .
2. be in the centre of the needle, as seen crosswise to the direction of sewing.
3. when the roller presser is lowered, the distance between the retainer **1** and the workpiece must be **0.2-0.3 mm**.



- Adjust retainer **1** (screw **2**) according to **Requirement 3**.
- Adjust bracket **3** (screw **4**) according to **Requirement 1 and 2**.




7.03.17 Knee lever

Requirement

1. before the roller presser rises, the knee lever must still have a slight play.
2. when the knee lever is raised as far as possible, the lever for the roller presser must drop automatically.
3. knee lever bar **5** must be at an angle of approx. 75° to the bedplate.



- Adjust screw **1** (nut **2**) according to **Requirement 3**.
- Adjust screw **3** (nut **4**) according to **Requirement 2**.
- Set bar **5** (screws **6**) according to **Requirement 3**.



Adjustment


7.03.18 Needle thread tension release

Requirement

1. when the presser bar lifter is raised, the tension discs **3** should be pressed at least **0.5 mm** apart.
2. When the roller presser is lowered, the tension must be fully effective.



- Align tension mounting plate **1** and pressure plate **2** according to Requirement.



7.03.19 Thread check spring

Requirement


1. the movement of thread check spring **7** should be completed when the needle point penetrate the fabric (spring stroke approx. **7 mm**).
2. when the largest thread loop is formed while the thread is passed around the hook, the thread check spring **7** should rise slightly from its support.



- Adjust support **1** (screw **2**) according to **Requirement 1**.
- Adjust the spring tension by turning screw **3** (screw **4**).
- Adjust the thread regulator **5** (screw **6**) according to **Requirement 2**.



For technical reasons it may be necessary to deviate from the specified spring stroke or spring tension. Move the thread regulator **5** (screw **6**) towards “+” (= more thread) or “-” (= less thread).



Adjustment


7.03.20 Bobbin winder

Requirement

1. when the bobbin winder is engaged, the winding spindle must be driven reliably. When the bobbin winder is disengaged, the friction wheel **5** must not be moved by drive wheel **1**.
2. the bobbin winder must switch itself off, when the filled thread is about **1 mm** from the edge of the bobbin.



- Position drive wheel **1** (screws **2**) according to **Requirement 1**.
- Position bolt **3** (screw **4**) according to **Requirement 2**.




7.03.21 Pressure of roller presser

Requirement

The material must be fed smoothly. No pressure marks should be visible on the material.



- Adjust roller pressure with screw 1 according to the **Requirement**.



Adjustment


7.03.22 Re-engage safety coupling



The coupling **1** is set by the manufacturer. When the thread jams, the coupling **1** disengages in order to avoid damage to the hooks. A description of how to engage the coupling follows.



- Remove jammed thread.
- Hold coupling **1** with screw **2** and turn the balance wheel, until you feel coupling **1** snap back into place again.



7.04 Adjusting the thread trimmer


7.04.01 Resting position of the roller lever/ radial position of the control cam

Requirement

1. when the thread trimmer is in resting position, lever **5** should be touching piston **6** and the roller of roller lever **7** should be **0.3 mm** away from control cam **3**.
2. when the take-up lever is at top dead centre, control cam **3** should just have placed roller lever **7** in its resting position.



- Having made sure that piston **6** is positioned against the left stop, adjust magnet **1** (2 screws) in accordance with **Requirement 1**.
- Adjust control cam **3** (screw **4**) in accordance with **Requirement 2**.



Adjustment

7.04.02 Position of the thread catcher holder

Requirement


1. there should be a minimum amount of play between toothed wheel **3** and toothed segment **4**.
2. both in the neutral position and the foremost position of the catcher, the distance between the toothed segment **4** and the outer edge of the thread catcher holder **1** should be the same (see arrow).



- Adjust the thread catcher holder **1** (screws **2**) according to **Requirements**.



If **Requirement 2** cannot be fulfilled, loosen screw **2** and move the toothed segment **4** by one tooth.




7.04.03 Distance between thread catcher and needle plate

Requirement

During its swivel movement thread catcher 1 should not pass the edge of the needle plate (see arrow).



- Move thread catcher 1 (screws 2, two screws) parallel to the thread catcher holder in accordance with the **Requirement**.



Adjustment

7.04.04 Position of the thread catcher

Requirement


1. the bottom edge of the thread catcher **1** should be at a distance of **0.1 mm** from the positioning finger of the bobbin case **5**.
2. when the thread trimmer is in its neutral position, the rear edge of thread catcher should be positioned approx. **2.5 - 3 mm** behind the edge of the knife.



- Move thread catcher **1** (screw **2**, two screws) in accordance with **Requirement 1**.
- Turn thread catcher **1** (screw **3**) in accordance with **Requirement 2**.




Thread catcher **1** must be parallel to the surface of the thread catcher holder **4**.



7.04.05 Bobbin thread retaining spring

Requirement

1. the bobbin thread clamp spring should be guided reliably in the thread groove of the thread catcher 3.
2. the tension of the bobbin thread spring clamp should be as low as possible, but the bobbin thread should be reliably after the cutting operation.



- Adjust bobbin thread clamp spring 1 (screw 2) in accordance with **Requirement 1**.
- Adjust the tension in accordance with **Requirement 2** by bending side 4 of the bobbin thread clamp spring 1.

Control requirement 1

- Switch off the machine and bring the take-up lever to its bottom dead centre.
- Engage and disengage the thread catcher 3 by hand and check **Requirement 1**. Adjust if necessary.

Control requirement 2


- After the thread has been cut, sew a few stitches by turning the balance wheel, checking whether the bobbin thread is drawn out of the bobbin thread clamp spring between the 1st and 3rd stitched, if necessary, correct the tension.

Adjustment

7.04.06 Manual cutting test

Requirement

1. when thread catcher **1** is on its forward stroke, it must not carry bobbin thread **3** forward too.
2. when thread catcher **1** is in its front position, bobbin thread **3** must be held reliably by hook **4**.
3. After the trimming action, both the needle thread and the bobbin thread must be perfectly cut and bobbin thread **3** retained.




- Sew a few stitches.
- Turn off the on/off switch.
- Carry out the cutting operation manually.
- Check **Requirement 1** and **2**, and if necessary readjust thread catcher **1** in accordance with **Chapter 7.04.04 Position of the thread catcher**.
- Check **Requirement 3**, and if necessary readjust the bobbin thread retaining spring **2** in accordance with **Chapter 7.04.05 Bobbin thread retaining spring**.

7.04.07 Releasing the tension

Requirement

When the magnet is activated, tension discs **3** must be at least **0.5 mm** apart.




- Activate the magnet.
- Detach the tension bearing plate **1** and adjust pressure plate **2**.

Adjustment

7.04.08 Linkage rod (only for the 8972)

Requirement

When the thread trimmer is in its resting position, the drive levers **1** must be parallel.



- Adjust drive levers **1** (screw **2**) in accordance with the **Requirement**.


Adjustment

7.05 Adjusting backtacking mechanism

7.05.01 Needle in needle hole (only for pneumatic machine)

Requirement

When the maximum stitch length is set, the needle must be the same distance from the inside edge of the needle hole, both for forward and reverse stitch.




● Turn crank 1 (screw 2) according to the **Requirement**,

Adjustment

7.05.02 Needle in needle hole (only for LP 98971)

Requirement:

When the maximum stitch length is set, needle bar should at lowest position.
Press back tacking spanner, needle bar should keep quiescent condition.




- Turn adjustment crank 2 (screw 1) according to requirement.

7.05.03 Coupling for roller presser drive

Requirement

There must be a distance of **3 mm** between coupling half 1 and locking disc 3 of the drive mechanism.




- Adjust coupling half 1 (screw 2) according to the **Requirement**.

Adjustment

7.05.04 Adjustment for roller presser clutch device (only for LP 8971)

Requirement

1. When sewing forwarders, turn up-feeding wheel by hand, up-feeding wheel by hand 4 just can be rotated in counterclockwise.
2. When sewing forwarders, turn up-feeding wheel by hand, up-feeding wheel by hand 4 can be rotated in counterclockwise and clockwise.




- Press back-tacking spanner 1.
- Adjust connecting pate 2 (screw 3) according to requirement.

7.05.05 Bevel gears for feed wheel drive (only for pneumatic machine)

Requirement

1. bevel gear 3 must fit well on the left side.
2. there must be a distance of **14 mm** between bevel gear 3 and bevel gear 5.



- Remove control unit 1 (screws 2).
- Adjust bevel gear 3 (screw 4) according to **Requirement 1**.
- Adjust bevel gear 5 (screw 6) according to **Requirement 2**.


Adjustment

7.05.06

Bevel gears for feed wheel drive (on the LP 8971)

Requirement

1. the right side of bevel gear 1 must be flush with its drive shaft (see arrow).
2. there must be a distance of **13 mm** between bevel gear 3 and bevel gear 1.




- Adjust bevel gear 1 (screws 2) according to **Requirement 1**.
- Adjust bevel gear 3 (screws 4) according to **Requirement 2**.

7.05.07 Bevel gear play (only for pneumatic machine)

Requirement

1. when sewing forwards, there must be a slight play between bevel gear 6 and 7.
2. When sewing backwards, there must be a slight play between bevel gear 6 and 8.



- Disconnect air supply of the air filter/lubricator.
- Move unit 1 by hand as far as possible to the right (see arrow).
- Adjust screw 2 (nut 3) according to **Requirement 1**.
- Move unit 1 by hand as far as possible to the left (see arrow).
- Adjust screw 4 (nut 5) according to **Requirement 2**.

DIRECT DRIVEN POST BED SEWING
MACHINE WITH WHEEL FEED AND DRIVEN
ROLLER PRESSER


PARTS LIST

CONTENT

A. Arm bed and its accessories.....	2
B. Presser bar parts.....	4
C. Needle bar holder parts.....	6
D. Thread tension regulator parts.....	8
E. Main shaft driving parts.....	10
F. Upper side shaft feed parts.....	12
G. Presser foot lifting parts.....	14
H. Bobbin winder parts.....	16
I. Stitch length adjustment parts.....	18
J. Clutch set parts.....	20
K. Oil lubrication parts.....	22
L. Hook parts (Left)	24
M. Left side bracket parts.....	26
N. Hook parts (Right)	28
O. Right side bracket parts.....	30
P. Bed plate feed parts.....	32
Q. Solenoid for thread trimming parts.....	34
R. Thread trimming driving parts.....	36
S. Solenoid for presser foot lifting parts.....	38
T. Upper feed and backstitch parts.....	40
U. Lower feed and backstitch parts for single needle.....	42
U. (一) Lower feed and backstitch parts for single needle.....	44
V. Lower feed and backstitch parts for double needle.....	46
W. Power cable connection.....	48
X. Parts of integrated machine.....	50
Y. Accessories.....	51

[illegible]


A. Arm bed and its accessories



B.Presser bar parts

[illegible]


B.Presser bar parts



C . Needle bar holder parts

No.	Part No.	Name	1NEEDLE	2 NEEDLE
1	7.02.01.353	Thread take-up assy.	1	1
2	7.02.10.462	Thread take-up fixed pin	1	1
3	7.02.09.003	Plastic stop ring	2	2
4	7.02.04.005	Needle bearing	2	2
5	7.02.05.003	Thread take-up holder	1	1
6	7.02.08.476	Thread take-up shaft bushing	1	1
7	7.02.15.049	Set screw	2	2
8		Screw	1	1
9	7.02.05.004	Thread take-up lever	1	1
10	7.02.04.004	Bearing	1	1
11	7.02.04.016	Bearing	1	1
12	7.02.18.030	Elastic retaining ring	2	2
13		Thread path	1	1
14	7.02.06.001	Thread take-up crank	1	1
15	7.02.05.005	Needle bar connector	1	1
16	7.02.04.006	Needle bearing	1	1
17	7.02.18.009	Washer	1	1
18	7.02.05.006	Needle bar fixer	1	1
19	7.02.15.066	Needle bar fixer screw	1	1
20	7.02.16.011	Oil felt	1	1
21	7.02.12.001	Needle bar connector guide slot	1	1
22	7.02.15.021	Guide slot screw	2	2
23	7.02.12.002	Needle bar guide slide block	1	1
24	7.02.16.012	Oil felt	1	1
25	7.02.17.005	Oil felt holder	3	3
26	7.02.15.964	Oil felt pressing plate screw	2	2
27	7.02.17.001	Fixed plate of needle bar holder		1
28	7.02.15.022	Fixed plate screw		1
29	7.02.15.064	Set screw		1
30	7.02.08.025	Bushing		1
31	7.02.08.026	Bushing		1
32	7.02.13.001	Needle bar holder	1	1
33	7.02.10.012	Pin	1	1
34	7.02.03.007	Main shaft	1	1
35	7.02.09.001	Collar	1	1
36	7.02.15.054	Set screw	1	1
37	7.02.03.018	Needle bar	1	1
38	7.02.08.024	Needle clamp bushing		1
39	7.02.15.040	Bushing screw		1
40	7.02.18.002	Disk type washer	2	
41	7.02.04.010	Needle bearing	2	
42	7.02.08.004	Bushing	2	
43	7.02.02.503	Needle holder		1
44		Needle holder screw		2
45	7.02.15.019	Needle clamp screw	1	
46	7.02.02.399	Needle holder	1	
47	7.02.14.112	Needle bar thread stand	1	
48	7.02.15.862	Screw	1	


C. Needle bar holder parts



D.Thread tension regulator parts

No.	Part No.	Name	1 Needle	2 Needle
1	7.02.01.280	Thread tension regulator assy.	1	
1-1		Nut	1	
2	7.02.01.282	Thread tension regulator assy.		1
2-1.		E type ring		1
2-2.		Thread tension plate(Small)	1	2
2-3.		Spring	1	2
2-4.		Screw	1	2
2-5.		Nut	1	1
2-6.		Screw	1	1
2-7.		Thread guide plate	1	2
2-8.		Screw	1	1
2-9.		Thread tension disk	2	4
2-10.		Tension disk	1	2
2-11.		Washer	1	2
2-12.		Washer	1	1
2-13.		Screw	1	1
2-14.		Adjusting spring	1	2
2-15.		Nut	1	2
2-16.		Position shaft		1
2-17.		Bushing collar		1
2-18.		Screw		1
2-19.		Screw		1
2-20.		Washer		1
2-21.		Spring adjuster		1
2-22.		Thread take-up spring		1
2-23.		Fixed plate		1
2-24.		Spring disk	1	2
2-25.		Washer	1	1
2-26.		Ring	1	1
2-27.		Thread take-up spring	1	1
2-28.		Thread tension stud	1	
2-28-1		Thread tension stud		1
2-29	7.02.15.960	Screw	1	1
2-30		Thread tension releasing plate	1	1
2-31		E type ring	2	2
2-32		Thread releasing pin	1	1
2-33		Thread releasing pin	1	1
2-34		Fixed pin	2	2
2-35		Thread releasing pin	1	2
2-36		Thread releasing pin	1	1
2-37	7.02.15.049	Screw	1	1
3	7.02.14.110	Lower thread guide claw	1	1
4	7.02.15.965	Lower thread guide claw screw	1	1
5	7.02.14.111	Thread stand	1	1
6	7.02.15.973	Thread stand screw	1	1


D.Thread tension regulator parts



E. Main shaft driving parts

[illegible]


E. Main shaft driving parts



F. Upper side shaft feed parts

[illegible]


F. Upper side shaft feed parts



G. Presser foot lifting parts

[illegible]


G. Presser foot lifting parts



H. Bobbin winder parts

[illegible]


H. Bobbin winder parts



I. Stitch length adjustment parts

[illegible]


I. Stitch length adjustment parts



J. Clutch set parts

[illegible]


J. Clutch set parts



K. Oil lubrication parts

[illegible]


K. Oil lubrication parts



L. Hook parts (Left)

No.	Part No.	Name	1 Needle	2 Needle
1	7.02.02.392	Hook assy.		1
1-1	7.02.02.393	Bobbin case		1
1-2		Elastic gasket		1
1-3		Screw		3
1-4		Screw		1
1-5		Needle guard slice		1
1-6		Screw		2
2	7.02.15.038	Screw		1
3	7.02.21.385	Bobbin		1
4	7.02.15.047	Screw		2
5	7.02.07.205	Driven gear		1
6	7.02.15.799	Screw (Long)		1
7	7.02.20.051	Thread trimming clamp plate		1
8	7.02.15.801	Screw		1
9	7.02.20.052	Movable knife		1
10	7.02.15.973	Screw		1
11	7.02.03.342	Driven shaft		1
12	7.02.10.458	Eccentric pin		1
13	7.02.15.433	Screw		1
14	7.02.20.050	Fixed knife		1
15	7.02.15.063	Screw (Short)		1
16	7.02.01.352	Movable knife bracket		1
17	7.02.10.370	Position pin		1
18	7.02.04.019	Bearing		1
19	7.02.04.018	Needle bearing		1
20	7.02.07.206	Gear		1
21	7.02.15.054	Screw		1
22	7.02.15.247	Set screw		2
23	7.02.18.255	Elastic retaining ring		1
24	7.02.18.256	Washer		1
25	7.02.11.386	Oil guard plate		1
26	7.02.08.545	Bushing		1
27	7.02.04.113	Bearing		1
28	7.02.18.257	Washer		1
29	7.02.04.020	Bearing		2
30	7.02.01.356	Bushing		1
31	7.02.04.009	Needle bearing		1
32	7.02.01.288	Thread distributing claw		1
33	7.02.15.420	Screw		1
34	7.02.01.289	Thread distributing claw bracket		1
35	7.02.16.300	Seal ring		1
36	7.02.11.385	Oil supply plate		1
37	7.02.15.577	Screw		1
38	7.02.16.303	Oil supply valve		1
39	7.02.15.022	Screw		1
40	7.02.16.047	Oil tube		1
41	7.02.16.309	Copper oil tube		1
42	7.02.03.340	Shaft		1


L. Hook parts (Left)



M. Left side bracket parts

No.	Part No.	Name	1 Needle	2 Needle
1	7.02.04.111	Bearing		1
2	7.02.18.253	Washer		1
3	7.02.13.29201	Left side bracket		1
4	7.02.04.110	Ball bearing		7
5	7.02.18.250	Elastic retaining ring		1
6	7.02.16.301	Oil felt		1
7	7.02.04.112	Needle bearing		2
8	7.02.08.393	Bushing		2
9	7.02.18.254	Elastic retaining ring		2
10	7.02.18.258	Washer		1
11	7.02.07.015	Gear (Large)		1
12	7.02.07.016	Gear (Small)		1
13	7.02.15.054	Screw		4
14	7.02.18.013	Washer		1
15	7.02.07.011	Gear (Small)		1
16	7.02.07.012	Gear (Large)		1
17	7.02.15.050	Screw		2
18	7.02.15.054	Screw		2
19	7.02.10.011	Adjusting pin		1
20	7.02.15.047	Screw		1
21	7.02.17.420	Spring plate		1
22	7.02.15.433	Screw		1
23	7.02.02.391	Post cap assy.		1
24	7.02.15.005	Screw		2
25	7.02.16.101	Plastic plug		1
26	7.02.04.016	Ball bearing		2
27	7.02.18.027	Elastic retaining ring		2
28	7.02.07.269	Gear		1
29	7.02.15.247	Screw		6
30	7.02.03.426	Shaft		1
31	7.02.15.041	Screw		1
32	7.02.15.268	Nut		1
33	7.02.09.080	Collar		1
34	7.02.15.054	Screw		2
35	7.02.06.278	Thread trimming crank		1
36	7.02.15.063	Screw		1
37	7.02.15.056	Screw		1
38		Washer		1
39		Screw		1


M. Left side bracket parts



N. Hook thread parts (Right)

[illegible]


N. Hook thread parts (Right)



O . Right side bracket parts

No.	Part No.	Name	1NEEDLE	2 NEEDLE
1	7.02.18.251	Elastic retaining ring	1	1
2	7.02.18.252	Washer	1	1
3	7.02.11.386	Oil guard plate	1	1
4	7.02.08.392	Bushing	1	1
5	7.02.09.080	Bushing collar	1	1
6	7.02.15.054	Screw	2	2
7	7.02.06.279	Thread trimming crank	1	1
8	7.02.15.056	Crank screw	1	1
9	7.02.15.063	Set screw	1	1
10	7.02.04.111	Bearing	1	1
11	7.02.18.253	Washer	1	1
12	7.02.17.420	Spring plate	1	1
13	7.02.15.433	Screw	1	1
14	7.02.13.29001	Side bracket (Right)	1	1
15	7.02.04.110	Ball bearing	1	1
16	7.02.18.250	Elastic retaining ring	1	1
17	7.02.16.301	Oil felt	1	1
18	7.02.04.112	Needle bearing	2	2
19	7.02.08.393	Bushing	1	1
20	7.02.18.254	Elastic retaining ring	1	1
21	7.02.09.115	Washer	1	1
22	7.02.15.054	Screw	2	2
23	7.02.07.011	Gear (Small)	1	1
24	7.02.07.012	Gear (Large)	1	1
25	7.02.15.050	Screw	2	2
26	7.02.15.062	Screw	2	2
27	7.02.11.384	Cover plate	1	
	7.02.11.486	Cover plate	1	
	7.02.11.485	Cover plate		2
28	7.02.15.973	Cover plate screw	8	10
29	7.02.18.003	Washer	2	2
30	7.02.15.965	Screw	2	2
31	7.02.10.011	Adjusting pin	1	1
32	7.02.15.035	Adjusting pin set screw	1	1
33	7.02.02.391	Post cap assy.	1	1
34	7.02.15.005	Set screw	2	4
35	7.02.02.500	Needle plate (small hole)		1
	7.02.02.502	Needle plate (middle hole)		1
36	7.02.15.032	Needle plate screw		2
37	7.02.13.38201	Support plate		1
38	7.02.15.006	Support plate screw		4
39	7.02.07.018	Feed wheel		1
40	7.02.17.017	Feed wheel position plate		1
41	7.02.15.017	Feed wheel position plate screw		2


O. Right side bracket parts



P . Bed plate feed parts

No.	Part No.	Name	1NEEDLE	2 NEEDLE
1	7.02.02.397	Needle plate(middle hole)	1	
	7.02.02.398	Needle plate(small hole)		
2	7.02.15.032	Needle plate screw	2	
3	7.02.15.965	Screw	2	
4	7.02.18.003	Washer	2	
5	7.02.13.28901	Support plate	1	
6	7.02.15.053	Screw	2	
7	7.02.18.016	Washer	2	
8	7.02.15.030	Screw	1	
9	7.02.10.010	Adjusting pin	1	
10	7.02.15.031	Adjusting pin set screw	1	
11	7.02.16.101	Plastic plug	1	
12	7.02.04.110	Ball bearing	1	
13	7.02.18.250	Elastic retaining ring	1	
14	7.02.04.016	Ball bearing	2	
15		Washer	1	
16	7.02.18.027	Elastic retaining ring	1	
17	7.02.08.017	Free-wheeling seat	2	
18	7.02.04.001	Needle bearing	2	
19	7.02.16.010	Oil felt	4	
20	7.02.05.001	Link	2	
21	7.02.15.958	Screw	4	
22	7.02.03.425	Shaft	1	
23	7.02.07.009	Bevel gear (Small)	2	
24	7.02.07.170	Bevel gear (Medium)	1	
25	7.02.15.054	Screw	4	
26	7.02.15.050	Screw	2	
27	7.02.08.035	Bushing	2	
28	7.02.15.049	Screw	2	
29	7.02.03.019	Shaft	1	
30	7.02.08.016	Bushing	2	
31	7.02.15.036	Screw	6	
32	7.02.16.004	Plastic joint	1	
33	7.02.08.015	Bushing	1	
34	7.02.09.002	Collar	1	
35	7.02.13.002	Bracket	1	
36	7.02.15.035	Screw	1	
37	7.02.15.061	Screw	2	
38	7.02.07.006	Feed wheel	1	
39	7.02.07.008	Bevel gear (Lower)	1	
40	7.02.07.007	Bevel gear (Upper)	1	
41	7.02.10.002	Roller bracket (Upper)	1	
42	7.02.10.004	Roller bracket (Lower)	1	
43	7.02.04.021	Ball (φ2)	24	
44	7.02.15.034	Screw	3	


P. Bed plate feed parts



Q. Solenoid for thread trimming parts

[illegible]


Q. Solenoid for thread trimming parts



R. Thread trimming driving parts

[illegible]


R. Thread trimming driving parts



S. Solenoid for presser foot lifting parts

[illegible]


S. Solenoid for presser foot lifting parts



T. Upper feed and backstitch parts

No.	Part No.	Name	1 Needle	2 Needle
1	7.02.19.347	Backtack solenoid (Upper)	1	1
2	7.02.17.417	Spring	1	1
3	7.02.18.330	Washer	1	1
4	7.02.18.223	Elastic retaining ring	1	1
5	7.02.05.449	Solenoid joint	1	1
6	7.02.10.455	Pin	1	1
7	7.02.13.377	Solenoid bracket	1	1
8	7.02.15.555	Solenoid fixed screw	2	2
9	7.02.10.453	Shaft	1	1
10	7.02.05.444	Crank (Front)	1	1
11	7.02.05.443	Crank (Back)	1	1
12	7.02.15.803	Screw	2	2
13	7.02.08.471	Shaft joint	1	1
14	7.02.10.454	Pin	1	1
15	7.02.04.002	Bearing	1	1
16	7.02.18.025	Elastic retaining ring	2	2
17	7.02.15.977	Screw	2	2
18	7.02.08.006	Connecting holder	1	1
19	7.02.15.017	Screw	1	1
20	7.02.08.005	Crank	1	1
21	7.02.15.053	Screw	1	1
22	7.02.05.001	Link	2	2
23	7.02.15.010	Screw	4	4
24	7.02.16.010	Oil felt	4	4
25	7.02.09.116	Washer	1	1
26	7.02.17.321	Spring	1	1
27	7.02.18.005	Washer	4	4
28	7.02.18.028	E type ring	4	4
29	7.02.04.001	Needle bearing	2	2
30	7.02.08.001	Free-wheeling seat	2	2
31	7.02.10.262	Pin	1	1
32	7.02.03.423	Shaft	1	1
33	7.02.07.267	Castle wheel (Upper)	1	1
34	7.02.07.268	Castle wheel (Lower)	1	1
35	7.02.15.054	Screw	2	2
36	7.02.02.390	Roller presser foot	1	1
37	7.02.05.002	Connecting holder	1	1
38	7.02.15.011	Screw	1	1
39	7.02.15.011	Washer	1	1


T. Upper feed and backstitch parts



U.Lower feed and backstitch parts for single needle

[illegible]


U.Lower feed and backstitch parts for single needle



U. (一) Lower feed and backstitch parts for single needle

[illegible]


U. (一) Lower feed and backstitch parts for single needle



V. Lower feed and backstitch parts for double needle

[illegible]


V. Lower feed and backstitch parts for double needle



W. Power cable connection

[illegible]

W. Power cable connection




X. Parts of integrated machine

[illegible]

X. Parts of integrated machine


[illegible]

X. Parts of integrated machine



Y. Accessories

[illegible]



1. Safety instruction

Please read the operation manual and related sewing machinery datasheet carefully before correct use.


1.1 (1) Power voltage and frequency: please refer to motor and control box nameplate.

(2) Interference from electromagnetic wave: please keep far away strong magnetic or high radiation environment in order to avoid obstructions and make to misoperation.

(3) Grounding: to avoid the noise obstructions or leakage of electricity accident (including sewing machine, motor, control box and positioner).

1.2 Please make sure power off at least 1min and then can open control box cover, because there are dangerous high voltage.

1.3 Please turn off the power while repairing or wearing needle in order to protect operator's safety,

1.4  Used where potential dangers exist.

 Used where high voltage and electric danger exist.

1.5 Product warranty period of one year on condition that this machine is operated correctly and no man-made damage.

2. System parameter table

591 : 9610 Roller feed postbed sewing machine (pneumatic) 591b : 9630 (electromagnet)

No	Project	Content	Applicable models	Setting range	The default value	Level
1	Sewing speed	Set sewing speed	591 591B	200~3500(rpm)	3000	I
2	Soft-start function	0 : No soft-start function 1~99 : Soft start stitches	591 591B	0~99	3	I
3	Ornamental bartacks	0 : Invalid 1 : Effective	591 591B	0/1	0	I
4	Fixed-length seam sewing speed	Set fixed-length seam sewing speed	591 591B	200~3500(rpm)	2500	I
5	Sewing mode	The sewing mode setting (without a nose operation box) 0 : Free sewing ; 1 : Simple Sewing 2 : Fixed stitches ; 3 : Overlapped sewing	591 591B	0~3	0	I
6	Forward stitches, bartack at the start of sewing	Forward stitches, bartack at the start of sewing (without nose operation box)	591 591B	0~32 (Needle)	3	I
7	Reverse stitches, bartack at the start of sewing	Reverse stitches, bartack at the start of sewing (without nose operation box)	591 591B	1~32 (Needle)	3	I
8	Forward stitches, bartack at the end of sewing	Forward stitches, bartack at the end of sewing (without the nose operation box)	591 591B	1~32 (Needle)	3	I
9	Reverse stitches, bartack at the end of sewing	Reverse stitches, bartack at the end of sewing (without the nose operation box)	591 591B	0~32 (Needle)	3	I
10	The number of steps of the fixed stitches	The number of steps of the fixed stitches (without nose operation box)	591 591B	1~7 (Paragraph)	1	I
11	Step 1 stitches		591 591B	1~99 (Needle)	15	I
12	Step 2 stitches		591 591B	1~99 (Needle)	15	I
13	Step 3 stitches		591 591B	1~99 (Needle)	15	I
14	Step 4 stitches		591 591B	1~99 (Needle)	15	I
15	Step 5 stitches		591 591B	1~99 (Needle)	15	I
16	Step 6 stitches		591 591B	1~99 (Needle)	15	I
17	Step 7 stitches		591 591B	1~99 (Needle)	15	I
18	The fixed stitches one-shot mode	The fixed stitches one-shot mode (without nose operation box set) 0 : Invalid 1 : Effective	591 591B	0/1	0	I
19	Function of stop after bartack at the start of sewing	Function of stop after bartack at the start of sewing 0 : Invalid 1 : Effective	591 591B	0/1	0	I
20	The manual switch function of the reverse feed stitching of sewing	0 : Only reverse feed stitching ; 1 : And needle compensation ; 2 : Only reverse feed stitching , standby does not work	591 591B	0~2	0	I
21	Soft-start speed 1	The first stitch speed	591 591B	100~3000(rpm)	600	I
22	Soft-start speed 2	The second stitch speed	591 591B	100~3000(rpm)	1000	I
23	Soft-start speed 3	The third stitch speed	591 591B	100~3000(rpm)	1500	I
24	Function of soft-down of presser foot	Function of soft-down of presser foot 0: Invalid 1: Valid	591 591B	0/1	0	I
25	Enable presser foot lift	0: Disable 1: Enable	591 591B	0/1	1	I
26	Enable automatic presser foot lift	0: Invalid 1 : Enable when stopped	591 591B	0/1	0	I
27	Up –position function	Automatic Up position function Power-on 0: Invalid 1: Valid	591 591B	0/1	0	I
28	Safety switch signal mode	0: Normally open 1: Normally closed 2: No protection	591 591B	0/1/2	0	I
29	The time of soft-down of pressure foot	The time of soft-down of pressure foot (time longer, down more slower)	591 591B	50~500(ms)	300	I
30	Unit of bobbin thread counting down	Unit of bobbin thread counting down 0: Invalid 5/10/15/20: count 5/10/15/20 stitches	591 591B	0/5/10/15/20	0	I

31	The bobbin thread initial total	The bobbin thread initial total	591 591B	200~4000	1600	I
32	Ornamental bartacks pause time	Ornamental bartacks pause time	591 591B	5~500(ms)	100	I
33	Times of reverse feed stitching sewing	0: double ; 1 : Four	591 591B	0/1	0	I
34	Standard bartacks,pedal speed source choice	0: automatic standard bartacks speed 1: pedal analog speed	591 591B	0/1	0	I
35	Cutting rate	0 : No function 1~20 : Every cutting rate 1~20,workpiece plus 1	591 591B	0~20	1	I
41	Slow speed	The lowest pedal speed	591 591B	100~400(rpm)	200	I
42	Pedal curve selection	0 : Normal;1 : Slow acc. ; 2 : Fast acc.	591 591B	0/1/2	0	I
43	Reverse limited feed speed	Reverse limited feed speed,when the manual switch closed	591 591B	500~1500(rpm)	800	I
*44	Cutting speed	Cutting speed	591 591B	100~400(rpm)	280	I
45	Reverse limited feed speed enable	0 : Disable 1 : Enable	591 591B	0/1	0	I
46	Delay Sewing time,when presser foot down	Delay Sewing time,when presser foot down	591 591B	0~800(ms)	200	II
47	Time of presser foot magnet full voltage output	Time of presser full voltage output	591 591B	0~800(ms)	150	II
48	Presser foot magnet voltage output duty cycle	Presser foot voltage output duty cycle	591 591B	0~100	50 30	II
49	Presser foot magnet lift holding time	Presser foot magnet lift holding time	591 591B	1~60(s)	12	II
50	Time of reverse feed stitching magnet full voltage output	Time of reverse feed stitching full voltage output	591 591B	0~800(ms)	120	II
51	Reverse feed stitching magnet duty cycle	Reverse feed stitching magnet duty cycle	591 591B	0~100	50	II
52	Reverse feed stitching magnet holding time	Reverse feed stitching magnet holding time	591 591B	1~60(s)	12	II
53	Speed of bartack at the start of sewing	Speed of bartack at the start of sewing	591 591B	100~3000(rpm)	1500	I
54	Bartack at the start of sewing compensation 1	Bartack at the start of sewing compensation 1	591 591B	0~100	20	I
55	Bartack at the start of sewing compensation 2	Bartack at the start of sewing compensation 2	591 591B	0~100	8	I
56	Speed of bartack at the end of sewing	Speed of bartack at the end of sewing	591 591B	100~3000(rpm)	1500	I
57	Bartack at the end of sewing compensation 1	Bartack at the end of sewing compensation 1	591 591B	0~100	20	I
58	Bartack at the end of sewing compensation 2	Bartack at the end of sewing compensation 2	591 591B	0~100	8	I
59	Overlapped sewing speed	Overlapped sewing speed	591 591B	100~3000(rpm)	1500	I
60	Overlapped sewing speed compensation 1	Overlapped sewing speed compensation 1	591 591B	0~100	20	I
61	Overlapped sewing speed compensation 2	Overlapped sewing speed compensation 2	591 591B	0~100	8	I
69	Down needle position	Down needle position	591 591B	120~240	60	I
70	Function of the reverse revolution after stopping up-position	0: Invalid 1: Valid	591 591B	0/1	0	I
71	Reverse revolution angle	Reverse revolution angle	591 591B	0~90(Degree)	45	I
75	Needle position adjustment	Reference 3. Gearing and adjustment	591 591B	0~240	0	II
79	Parameter restore	Set to 5: Restore the current level of the factory parameters	591 591B	0~15	0	I
80	Sewing maximum speed	Sewing maximum speed	591 591B	200~3500(spm)	3000	II
81	Lubrication prompts	0: Invalid ; 50~1000: Suggestion time	591 591B	0~1000 (Hour)	0	II
83	Retry function	This function is used when needle cannot pierce materials. 0: Normal ; 1: Retry function is provided.	591 591B	0~15	0	II
85	Cutting magnet pull angle	Cutting magnet pull angle	591 591B	0~120	60	II
87	Cutting magnet release angle	Cutting magnet release angle	591 591B	270~360	320	II
88	Loose magnet pull angle	Loose magnet pull angle	591 591B	270~360	300	II
89	Up dead position angle	Up dead position angle	591 591B	270~360	290	II
90	Wheels ratio	Wheels ratio	591 591B	800~1200	1000	II
92	Pedal presser foot lift confirm time	Pedal presser foot lift confirm time	591 591B	10~300(ms)	80	II

Do not change the set values With * mark as they are functions for maintenance. If you change the factory initial settings, there may be damage to the machine or reduce the risk of machine performance. If it is necessary to change, you need professional guidance. But sometimes in order to improve the functionality and performance of the sewing machine, it is possible at any time to change the function.

3.Gearing and adjustment

1. Please press the P key for more than 3 seconds at the default interface , and then input the password "1111" .
2. Press the P key for seconds into the parameter.
3. Select the No.75 parameter ,run machine at 200rpm speed.
4. Stop sewing machine, after running for several turns.
5. Check the position of the needle,and then turn the hand wheel till the needle' s point touches the board (as shown in the right figure,and the value of the No.75 will change at the same time)
Step the pedal again and check that if the needle' s point touches the board after the machine stopped, if not,adjust the hand wheel again.
6. Press the P key,and then end the operation.




4.Operation box use

4.1 Description of function keys

Function	Butto n	Described	
Bartack(start sewing)		Execution start bartack once or twice	
Bartack(end sewing)		Execution end bartack once or twice	
Free sewing		Step the pedal,then running machine,return it,then stopped,step pedal back,then do cutting and other action.	
Overlapped sewing		1. Step the pedal,then running machine, the overlapped number set by the E segment, up to 99 times 2. This sewing is one-shot mode. 3. Bartack at the start & end of sewing is not valid.	
fixed stitches mode		1. Step the pedal, running CD sewing stitches. 2. Return the pedal, sewing immediately stopped, step again, running the remainder stitches. 3. When finished CD stitches,then execute to end bartack(optional)and cutting etc. action.	
Cutting		Set or cancel the trimming function	
stitch compensation		Peform needle up/down compensating stitching,or one stitching compensating or more stitching according to time long or short.	
Speed adjust key		Decrease speed keys, the display automatically switches to the speed setting. Simple sewing, free sewing effective.	
		Increase the governor keys, the display automatically switches to the speed setting. Simple sewing, free sewing effective.	

4.2 The control box operation panel describe

As shown in the right figure.



4.3 sewing function setting

Operation panel default mode:

Needle position , trimming,start bartack and end bartack

- | | |
|-------------------------------|--|
| 1 : choice of needle position | a : 0 up needle position ; 1 lower needle position |
| 2 : choice of trimming | b : 0 no-trimming trimming 1 trimming |
| 3 : choice of start bartack | c : 0 no ; 1 AB double ; 2 ABAB four |
| 4 : choice of end bartack | d : 0 no ; 1 CD double ; 2 CDCD four |

4.4 Function parameter setting

Press the P key long to enter the function parameter setting state at the default interface.

Abcd postion show parameter value,can be modified by the key 34; ef postion show parameter index,can be modeified by key 12.

Press P can save the current parameter values,then exit the parameter setting mode. Press 1234 key short time,then update every time,press long time,update continuance and faster.

Note: When the system is running, can not enter the parameter setting mode; unless you exit the parameter setting mode, otherwise the system can not run.

4.5 System monitor state

Press the P key,at the same time press key 1 ,can enter this interface at the default interface.

JJ	Work pieces	DX	Bobbin thread value	1	Motor speed	2	Motor current	3	Bus voltage
4	Pedal voltage	5	mechanical angle	6	motor angle	7	Software Version	8	machine model

5. Error codes

Error Code	Contents	Possible reasons	Checking and treatment
E011 E012 E013 E014	Motor signal error	Motor position sensor signal failure	If electric engine plug is well contacted; if electric engine signal detecting device has been broken; if sewing machine handwheel correctly installed.
E015	Model type error	Unable identify operating box model type	Check operating box
E021 E022 E023	Motor overload	motor stall motor overload	If electric engine plug is well contacted; if machine head or thread-cutting mechanism has been blocked completely;f materials are too thick; Electrical signal detection signal whether the normal.
E101	Hardware drivers fault	Current detection abnormal Driving hardware error	Current detection loop system is working properly;Whether the damage to the device driver.
E111 E112	Voltage too high	High input voltage Brake circuit fault Voltage detection error	System into line voltage is too high; Braking resistance are working properly; System voltage detection circuit are working properly.
E121 E122	Voltage too low	Actual low voltage Voltage detection is wrong	If the voltage on the inlet wire is too low Whether the system voltage detection circuit the normal work.
E131	Current circuit fault	Current detection abnormal	Current detection loop system is working properly.
E133	Oz circuit fault	Oz circuit fault	Oz circuit system is working properly.
E151	Magnet circuit error	Over current magnet circuit	If machine head magnet suffers short circuit Electromagnet circuit is working properly.
E201	over current	Current detection error	Current detection loop system is working properly Electrical signal is normal.
E211 E212	Abnormal motor operation	Current or voltage detection error	If electric engine plug is well contacted; If electric engine signal is matched.
E301	Communication error	Sci circuit error	if operation box plug is well contacted; if operation box components are damaged.
E302	Operation inner failure	Sci circuit error	To check whether the operating box is damaged..
E402	Pedal ID fault	Pedal verification fault	Pedal connection is loosen.
E403	Pedal zero position fault	The pedal zero position over range	The pedal is damaged or it is not under stop state when correction.
E501	Safety switch fault	Safety switch effective	Put down the head or check turned up switch.
P.oFF	Power off Display	Power off	Wait for power supply to resume.

Note: 1. Sewing abnormal action (speed electromagnet work abnormal) : in the control interface view model is correct;

2. Turn up E501 fault when: sure it is normal to switch detection, temporary use can change the P-28 parameters;

3. If the above according to check the project cannot rule out fault, please seek technical support.

6. Accessory

NO	Product name	Amount	Product specification	Confirm	Remarks
1	Ball section connecting rod	1			
2	Electric control box	1			
3	Operating box	1	EP-003		
4	Pedal	1	PL-303		Including stand
5	Machine press key	1			
6	Ctrolling box fixed screws	3	M5×25		Accessory box
7	Pedal fixed screws	3	M5×25		Accessory box
8	Stand connector fixed cover	1			Accessory box
9	Connector fixed screws	1	M5×15 Self-tapping		Accessory box
10	Operating box stand fixed screws	1	M6×16		Accessory box
11	Motor and stand fixed screws	4	M5×20		Accessory box
12	Operating box fixed screws	3	M4 × 8/ plated withblue and white zinc		Accessory box
13	Motor	1	80SF110-B3000-A01		
14	The instructions	1			
15	Certificate	1			
16	Desiccant	1			